

User Manual

Three Phase
On Grid Inverter CE3P40-60KEG

 CHISAGE ESS

CHISAGE ESS

🔍 www.chisageess.com

Copyright © ZHEJIANG CHISAGE NEW ENERGY TECHNOLOGY CO.,LTD.

Without written permission, any information of this document (partly or entirely) cannot be extracted, copied or transmitted in any form or by any means. All right reserved.

Notice:

The information in this document is subject to change without notice. Please adhere to the actual products in case of any discrepancy. Any statements, description, and recommendations in this manual do not constitute a guarantee or warranty of any kind, explicitly or implicitly.

Warranty:

Warranty terms and conditions can be downloaded from the Internet at www.chisagess.com.

Contents

1. About the Manual	2
2. Product Overview	3
3. Safety	6
4. Mounting	7
5. Electrical Connection	10
5.5 Over Current Protection Device	14
5.6 Communications Connection	15
5.7 Electrical Connection Overview	16
5.8 Meter and CT Installation (optional)	16
5.9 Residual Current Device (RCD)	18
5.10 DRM (Demand Response Mode)	18
6. Operation	19
6.1 Start and Stop Inverters	19
6.2 LCD Operation	20
6.2.1 Main Menu	20
6.2.2 Basic Info	21
6.2.3 BASIC SETUP	24
6.2.4 Detail Info - Maintenance Personnel Only	25
6.2.5 Technical Set – Maintenance Personnel Only	30
7. Maintenance and Troubleshooting	44
7.1 General Maintenance	44
7.2 Disposing of Inverters	44
7.3 Storage and Transportation	44
7.4 Troubleshooting	45
8. Specification	51

1. About the Manual

The manual describes product information, mounting, installation, operation, maintenance, troubleshooting and specification of inverters.

Validity

The document is valid for the following inverter models: CE-3P40KEG, CE-3P50KEG, and CE-3P60KEG.

Target Group

The target group of this manual are end users and qualified persons who have knowledge of inverters or skills of inverter installation, maintenance, etc. Only qualified persons are allowed to perform the installation and activities marked in this document under the guidance of safety instructions. Please read this manual carefully before conducting any kind of work on the inverters.

Valid Region


This manual applies to the operation of Chisage ESS inverters in Australia, New Zealand, the UK, EU, South America, North America, and Southeast Asia.

2. Product Overview

2.1 Product Description

CE-3P40KEG, CE-3P50KEG, and CE-3P60KEG three phase on-grid inverters convert DC power generated by photovoltaic panel arrays into AC power and feed the converted AC power into utility grid.


Product Appearance:



No.	1	2	3	4	5	6	7	8	9
Name	PV Inputs	DC Switch		CT Port	Communic ations Port (Meter & DRM)	Wifi Port	Commun ication Ports 2	Grounding Port	AC Output

2.2 Front Panel

Operation Panel:




No.	1	2	3	4	5	6	7	8
Name	Communications Light	Power Light	Alarm Light	LCD	ESC	Up	Down	Enter

LED Light:

Light	Status	Explanation
 POWER	ON	The inverter is generating power
	OFF	The inverter is not generating power
 COMMUNICATIONS	ON	The inverter has been connected to the Internet
	OFF	The inverter has not been connected to the Internet
 ALARM	ON	Alarm or fault has been detected
	OFF	The inverter is operating normally

2.3 Scope of Delivery



No.	Description	Quantity
1	Inverter	1
2	Wall Bracket	1
3	Expansion Screws	4
4	Fastening Screws(M5)	1
	Fastening Screws(M6)	2
5	DC Connectors	8-12 (pairs)
6	AC Connectors	1
7	WiFi/GPRS logger	1
8	Documents	1

3. Safety

3.1 Safety Symbols

Symbol	Explanation
 DANGER	Indicates a high level of risk which, if not avoid, may result in death or serious injury
 WARNING	Indicates a medium level of risk which, if not avoid, may result in death or serious injury
 CAUTION	Indicates a low level of risk which, if not avoid, may result in minor or moderate injury
 NOTE	Indicates a situation which, if not avoided, may result in device damage or property damage
 ELECTRIC SHOCK	Indicates a danger of electric shock or high voltage
 HOT SURFACE	Indicates hot surface, do not touch
 WAIT	Notice of waiting at least 5 minutes before operation

3.2 Safety Instructions and Notice for Use

The inverters involved in this manual comply with applicable safety and technical regulations in design and test. To avoid personal injury and property damage and to ensure longer service life of the machines, please read this manual carefully and observe all safety information during operation.

Improper operation may result in risk of person injury or damage to the machine and to other property, so please ensure that the following

requirements are met before or during operation.

- Installation of inverters must be performed by qualified technicians, and be in compliance with applicable electrical standards, regulations and the requirements of local power authorities.
- Wear protective equipment for all work on the machines: helmet, insulated footwear, gloves, etc.
- Ensure that unauthorized persons and children have no access to the machines.
- Do not open the housing of the machines at any time. Unauthorized opening will void guarantee and warranty and may damage the machines.
- Do not touch non-insulated parts or cables, disconnect the machines from voltage sources and guarantee no possible re-connection before working on the machine.
- Use measuring devices with a DC input voltage range of 1100 V or higher only.
- High voltage is present in the live parts and cables inside the product during operation, wait at least 5 minutes after disconnecting voltage sources.
- The temperature of some parts of the inverter may exceed 60 °C during operation. To avoid being burnt, do not touch the inverter during operation.
- Pack inverters properly during transportation, and do not transport them together with flammable material.

4. Mounting


4.1 Installation Location

**WARNING**

Do not select locations storing flammable material which may cause fire or explosion!

The following points should be considered when selecting an installation location.

- The wall bearing inverters shall be able to hold the weight of at least 4 times of the weight of the inverters.
- The location shall be convenient for electrical connection, operation and maintenance.
- The ingress protection of the inverter is IP66, so it can be installed both indoors and outdoors.
- The temperature of the cooling fan may exceed 75 °C, so select safe locations.
- The location must be well ventilated and sheltered from direct sunlight, rain or snow.
- Ensure the visibility of the LED lights and LCD display on the front panel of inverters.
- Install inverters vertically or with a backward tilt within 15 degrees. No lateral tilt is allowed.
- If more than one inverter are installed in one location, a minimum 150 mm clearance should be kept between two inverters and a minimum 300 mm clearance between inverters and the ground.




- The Inverter is to be installed in a high traffic area where the fault is likely to be seen.


4.2 Inverter Mounting

Procedures:

- 1) Ensure that the bracket is horizontal. Mark the position of the drill holes. For brick walls, the position of the holes should suit expansion screws.
- 2) Use a 10 mm drill bit to drill mounting holes of 40 mm deep.
- 3) Insert the expansion tubes into holes.
- 4) Screw the expansion screws into expansion tubes with a cross screwdriver to fix the bracket on the wall.



- 5) Lift up the inverter, and hang it on the mounting bracket securely.
- 6) Lock the inverter to the mounting bracket with screws.



5. Electrical Connection

5.1 DC Side Connection of Inverters

5.1.1 PV Array Configuration

This inverters are compatible with monocrystalline silicon, polycrystalline silicon, and thin-film PV panels. The recommended PV array matching the inverters are listed below:

$1.25 \times I_{sc}$ of each PV string $\leq$ PCE(Inverter) DC input I_{sc}

V_{oc} of each PV string ≤ 1100 V.



NOTE: PV arrays should be under the protection of over voltage class II. For the grounding of the PV array, the frame of panels should contact the rail, and the the grounding cable connect the rail.



DANGER ELECTRICAL SHOCK

Lethal high voltage will be generated by PV arrays under sunlight, so please disconnect DC and AC breakers and ensure no possibility of re-connection before conduct electrical connection!

PV strings should be connected to the inverter through special PV connectors that are in the scope of delivery.



NOTE: Use only the supplied connector or the connector with IP 65 or above to guarantee that the protection ingress of the whole inverter is IP66!


It is recommended to use the DC cable of 4 mm² or 6 mm².




NOTE: Use DC cables specialized for photovoltaic systems Only!

Assemble DC cables to DC connectors:

- 1) Strip the insulation layer off the DC Cable for a little length.
- 2) Insert the wire into the Crimp Contact and crimp them with an electrical crimp-er.



- 3) Thread the cable through the Cable Gland, insert it into the insulator, and gently pull backward the cable to ensure firm connection. Then screw up the Cable Gland to the Insulator.



Install the DC connectors to the Inverter:

- 1) Turn the Grid Supply Main Switch OFF.
- 2) Turn the DC switch OFF.
- 3) Connect the DC connectors to the Inverter, small click confirms connection. Please guarantee the correct polarity of the connection.

Please prioritize the use of the PV Inputs of right side.



WARNING


Ensure that the open circuit voltage of PV array is within the max. input voltage of the inverter!



WARNING: Do not turn off DC switch directly for accident reverse connection of DC inputs or any fault of inverters as it may damage inverters. In that case, turn off the DC switch only when the DC current is below 0.5 A.


5.2 AC Side Connection of Inverters

An AC Connector is supplied together with the inverter.




Procedures:

- 1) Strip the insulation layer off the AC cable about 25 to 30 mm.



- 2) Lead the stripped wires through the nut, seal ring, and house, insert the wires into corresponding holes of terminal Block which is already assembled in the AC port of the inverters by the manufacturer, and fasten the wire to the terminal block with a screwdriver.



- 3) Push the housing to the terminal block and a sound of click will be heard after success of fastening. Then screw up the nut tightly.

5.3 External Grounding Connection


The external grounding port is located beside the AC connection terminal of the inverter. The parameters of designed external protective earthing conductor and screw are as below:

M4 screw with the cross-sectional area of 6.1 mm^2 ;

AWG8 conductor with the cross-sectional area of 8.4 mm^2 .

Procedures:

Prepare an OT terminal M4, crimp a grounding cable to the terminal, insert a fastening screw into the OT terminal, insert them to the grounding port on the inverter, and screw them tightly.



5.4 Earth Fault Alarm

The inverters are designed with an earth fault alarm function. If an earth fault occurs, the inverters will stop generating power, the red alarm light will be on and the LCD will display 'ISO Out Range' or 'PEN No Connect'. In that case, please refers to Chapter 7 for troubleshooting or contact Chisage ESS for help.


5.5 Over Current Protection Device

It is recommended to install a breaker (over current protection device (OCPD)) to protect the AC grid connection conductors. The table below is the recommended parameter of an OCPD ratings for the Inverter.

Inverter	Rated output voltage (V)	Rated output current (A)	Current for protection device (A)
CE-3P40KEG	230/400	58	80
CE-3P50KEG	230/400	72.5	100
CE-3P60KEG	230/400	87	100


5.6 Communications Connection

5.6.1 Communications overviews



5.6.2 WiFi/GPRS Stick Installation


Assemble WiFi/GPRS stick to the corresponding port on inverter as shown in the diagram.



- 1) Plug the stick to the Wifi port on the inverter
 - 2) Rotate the front operative part of the stick clockwise till the secure connection of the stick
- More detailed information about communications can be found in corresponding manuals.

5.7 Electrical Connection Overview

The following is a diagram of a typical solar system for your reference to install inverters.



5.8 Meter and CT Installation (optional)

A meter and CT(current transformer) can be connect to corresponding ports on inverter to monitor electricity parameter such as current, voltage, power, etc. and to realize export power management.

The suggested parameter:

Max input current for meter: 80A

Max measuring current for CT: 100A

Detail specifications of meter and CT can be found on Chisage ESS Website and a customer can purchase a suitable meter and CT for inverters on the website.




NOTE

No need to change any parameter of the meter as it has been preset in the factory!

Meter and CT connection:

For more information about meter and CT connection, please refer to corresponding manuals on Chisage ESS website.

The following is schematic diagrams for reference.



CT Installation Electrical Diagrams



DANGER ELECTRICAL SHOCK

Turn off upstream and downstream electrical connection before the meter installation!

5.9 Residual Current Device (RCD)

An internal residual current device is integrated in the inverter to protect against any potential residual current. If the residual current that exceeds a set limit is detected, the inverter will stop working, the warning light will be on and the LCD will display 'GFCI Device Fault' or 'GFCI Out Range'.

If you need to install an external RCD as required by local grid company, we suggest a Type-A RCD with a threshold current higher than 100 mA.

5.10 DRM (Demand Response Mode)

The DRM port is only applicable to installations in Australia and New Zealand. The inverter detects and initiates a response to the demand response modes listed in the following table.

Mode	Functions
DRM 0	Operate the disconnection device
DRM 5	Do not generate power
DRM 6	Do not generate at more than 50 % of rated power
DRM 7	Do not generate at more than 75 % of rated power AND absorb reactive power if capable
DRM 8	Increase power generation (subject to constraints from other active DRMs)

Ways to connect a DRED (demand response enabling device) to inverters

- 1) Assemble a RJ45 connector by connecting a network cable to the RJ45 according to the international conventional method;
- 2) Plug the RJ45 connector to the DRM port of the inverter.

Power rate limit modes as required by Australia and New Zealand's safety standard is supported in this inverters. When a demand response mode (except for DRM 0) is asserted or unasserted the power rate limit will apply to the increase or decrease in power generation or consumption and the

transitions between power levels.

When a DRED is connected to an inverter, the inverter will receive and response to the outside signal directly. And the DRM working mode will be shown in the BASIC INFO in the LCD menu.

6. Operation

6.1 Start and Stop Inverters

6.1.1 Inverter Turning-on

The following procedures have to be followed exactly to start an inverter.

- 1) Turn on the AC breaker.
- 2) Turn on the DC Switch.
- 3) After a compulsory delay of 30 to 300 seconds, the inverter will start to work and the POWER light will be on.



WARNING

Ensure that the open circuit voltage of PV array is within the max. input voltage of the inverter!



DANGER ELECTRIC SHOCK

High voltage may present, please beware of the risk of electric shock and take protection precautions!

6.1.2 Inverter Turning-off

The following procedures have to be followed exactly when stop an inverter.

- 1) Switch off the AC Main Switch.
- 2) Wait around 30 seconds for the capacitor to dissipate energy. Then turn

the DC switch OFF.

3) Be sure that all LED light is OFF (around 1 minute).




CAUTION WAIT

Beware of the risk of electrical shock! Wait at least 5 minutes before touching the machine although the DC switch has been turn off!

6.2 LCD Operation

6.2.1 Main Menu

When the inverter has been started, the LCD screen shows operation status and power of the inverter alternately every 10 seconds (refer to below figure). You can press UP and DOWN keys to scroll the screens and press ENTER key to access the main menu. The main menu includes four sub-menus: BASIC INFO, BASIC SETUP, DETAIL INFO, and TECHNICAL SET.



6.2.2 Basic Info.

The table below explains the meaning of information displayed in the sub-menu of Basic Info.

No.	Displays	Duration	Explanation
1	TOTAL ENERGY 50000 Kwh	10 S	Total energy: total energy generated
2	ThisMon: 255Kwh LastMon: 254Kwh	10 S	This Month: total energy generated this month Last Month: total energy generated last month
3	TODAY: 52 Kwh PRE_DAY : 54Kwh	10 S	This Day: total energy generated today Previous Day: total energy generated yesterday
4	DC VOL1: 401.5V DC CUR1: 18.6A	10 S	DC voltage1: the DC voltage of the PV input 1 DC current1: the DC current of the PV input 1
5	DC VOL2: 408.5V DC CUR2: 18.6A	10 S	DC voltage2: the DC voltage of the PV input 2 DC current2: the DC current of the PV input 2
6	DC VOL3: 401.5V DC CUR3: 18.6A	10 S	DC voltage3: the DC voltage of the PV input 3 DC current3: the DC current of the PV input 3

7	DC VOL4: 401.5V DC CUR4: 18.6A	10 S	DC voltage4: the DC voltage of the PV input 4 DC current4: the DC current of the PV input 4
8	DC VOL5: 401.5V DC CUR5: 18.6A	10 S	DC voltage5: the DC voltage of the PV input 5 DC current5: the DC current of the PV input 5
9	DC VOL6: 401.5V DC CUR6: 18.6A	10 S	DC voltage6: the DC voltage of the PV input 6 DC current6: the DC current of the PV input 6
10	DC VOL7: 401.5V DC CUR7: 18.6A	10 S	DC voltage7: the DC voltage of the PV input 7 DC current7: the DC current of the PV input 7
11	DC VOL8: 401.5V DC CUR8: 18.6A	10 S	DC voltage8: the DC voltage of the PV input 8 DC current8: the DC current of the PV input 8
12	DC VOL9: 401.5V DC CUR9: 18.6A	10 S	DC voltage9: the DC voltage of the PV input 9 DC current9: the DC current of the PV input 9
13	DC VOL10: 401.5V DC CUR10: 18.6A	10 S	DC voltage10: the DC voltage of the PV input 10 DC current10: the DC current of the PV input 10
14	DC VOL11: 401.5V DC CUR11: 18.6A	10 S	DC voltage11: the DC voltage of the PV input 11 DC current11: the DC current of the PV input 11

15	DC VOL12: 401.5V DC CUR12: 18.6A	10 S	DC voltage12: the DC voltage of the PV input 12 DC current12: the DC current of the PV input 12
16	AC VOL A: 230.6V AC CUR A: 38.8A	10 S	AC voltage A: the voltage of the utility grid live line A AC current A: the current of the utility grid live line A
17	AC VOL B: 230.6V AC CUR B: 38.8A	10 S	AC voltage B: the voltage of the utility grid live line B AC current B: the current of the utility grid live line B
18	AC VOL C: 230.6V AC CUR C: 38.8A	10 S	AC voltage C: the voltage of the utility grid live line C AC current C: the current of the utility grid live line C
19	FREQ A :50.2Hz POWER A: 1200 W	10 S	Frequency of A Phase Power of A Phase
20	FREQ A :50.2Hz POWER A: 1200 W	10 S	Frequency of B Phase Power of B Phase
21	FREQ A :50.2Hz POWER A: 1200 W	10 S	Frequency of C Phase Power of C Phase
22	TOTAL POWER 3600 w	10 S	The total output power 3600W
23	TOTAL RUNTIME: 152 H	10 S	Cumulative energy generation time

24	INVERTER SN CE00S005000001A1	10 S	Inverter SN: The SN of the Inverter CE00S005000001A1
25	MODEL: Volt-Watt DRM : DRM5	10 S	Working Mode: Volt-Watt DRM NO. : DRM5
26	Standard cEN50549_1	10 S	The grid connection standard

6.2.3 BASIC SETUP

You can set time and address in this sub-menu.

No.	Display	Explanation
1	SET TIME	To set up time
2	SET RS485 ADDR	To set up RS485 address
3	SET LANGUAGE	To set up language

6.2.3.1 Time Setting-up

When the sub-menu of 'SET TIME' is selected, the LCD will display the screen as below.

NEXT = ENT OK = ESC
25-01-2022 18:23

Press ENT to move the cursor from left to right, Press UP/DOWN to select a number for a selected digit. Press ESC to save the setting and return to the main menu.

6.2.3.2 Address Setting-up

The inverter RS 485 address communicating with a monitoring platform can be set here, the address ranges from '01' to '99', and the default address is '01'.

YES = ENT EXIT = ESC
Slave Add: 01

Press UP/DOWN to scroll through numbers for a selected digit, press ENT to save the setting and return to the main menu, and press ESC to return to the main menu without saving the setting.

6.2.3.3 Language Setting-up

Working language of the inverter can be set here, and the default language is English.

6.2.4 Detail Info - Maintenance Personnel Only

Select 'Detail Info' from the main menu and the LCD screen will display the following information:

NEXT = ENT EXIT = ESC
Password: 1000

Steps to view the menu of the Detail Info.:

1) Enter the password:

The default password of the inverter is 1000. When finishing password entering, press ENT to verify the password. If the password is correct, the sub-menu will be displayed, and if wrong, the LCD will display 'Wrong Password' and return to the previous menu. Press ESC to return to the main menu.

2) Access the sub-menu:

After enter the correct password, the sub-menus will be displayed:

1. Operation Info, 2. Fault Info, 3. Flash Version, 4. Warning Info, 5. SW

Version, 6. Rated Power, 7. Rated Voltage, 8. Daily Energy, 9. Monthly Energy, 10. Yearly Energy, 11. Export Total, 12. Export Today

Press UP/DOWN to scroll the screen, press ENT to go into the selected sub-menu and press ESC to return to the main menu.

6.2.4.1 Operation Information

This information is for maintenance personnel to get the operation information, and the information is as below:

No.	Display	Duration	Explanation
1	GFCI RMS: 10 mA ISO : 1.25 k Ω	10 S	This menu indicates: GFCI RMS: Leakage current protection ISO: Ground fault protection/Insulation Resistance
2	Heatsink Temp 65.5 $^{\circ}\text{C}$	10 S	This menu indicates: The temperature of heat sink of inverters
3	Inv Inner Temp 45.0 $^{\circ}\text{C}$	10 S	This menu indicates: Inverter inner temperature
4	BusVol: 385.5V DCI A : 0 mA	10 S	This menu indicates: Bus voltage AC direct component of Phase A
5	DCI B : 0 mA DCI C : 0 mA	10 S	AC direct component of Phase B and C
6	PF:+1.00 ac Pac Limit: 80%	10 S	This menu indicates: Power factor ratio Output power limit

7	BusHalfVol: GridFilter: ON	10 S	Half Voltage of Bus Grid filter grade
8	RCD(GFCI): ON PVISOGuard: ON	10 S	This menu indicates: Residual current protection Insulation Resistance/Ground fault protection
9	AllPVParal: ON MPPTShadow:	10 S	This menu indicates: All PV in parallel mode MPPT shadow mode
10	RelayCheck:OFF DCI Prot : ON	10 S	This menu indicates: Self examination of AC relay Output direct component protection
11	Apparent Power 2000 VA	10 S	This menu indicates the apparent power
12	Active Power 2000 W	10 S	This menu indicates the active power
13	Reactive Power 2000 Var	10 S	This menu indicates the reactive power
14	Export Power 4800W	10 S	This menu indicates the power exported to grid

The operation info of inverter and part of protection info. can be view after password has been input and all the info. is included in the above table. Press UP/DOWN to scroll the screen to view.



NOTE: This operation is for maintenance personnel only. Password is required to access this part!

6.2.4.2 Fault Info.

When a fault happens, the Alarm Light will be on, and the LCD will display a brief description of the fault. Please refer to Chapter 7 for troubleshooting or contact after-sales department if a fault info. is displayed.

ACHCT Device
Fault

6.2.4.3 Flash Version

The flash version can be checked here.

Flash Version
ES 3.0

6.2.4.4 Warning Info.

If a adverse condition presents in the inverter, the LCD will display a warning information. The inverter will work normally with such warning conditions. When a warning info. is displayed, please refer to Chapter 7 for troubleshooting.

Warning Info
0x00000400

6.2.4.5 Software Version/Firmware Version

The software version or firmware version of the inverter is displayed and is accessible for technicians only.

SW Version
V01.05

6.2.4.6 Rated Power

The rated power of the inverter is displayed here.

Rated	Power
5KW	

6.2.4.7 Rated Voltage

The rated voltage of the inverter is displayed here.

Rated	Voltage
220V	

6.2.4.8 Daily Energy

The energy generated for a specified day can be checked here.

Select	Day
2020-02-22	

6.2.4.9 Monthly Energy

The energy generated for a specified month can be checked here.

Select	Month
2020-02	

6.2.4.10 Yearly Energy

The energy generated for a specified year can be checked here.

Select Year	
2020	

6.2.4.11 Export Total

Total energy exported to grid can be checked here.

Export	Total
500KWh	

6.2.4.12 Export Today

The energy exported to grid today can be checked here.

Export	Today
500KWh	

6.2.5 Technical Set – Maintenance Personnel Only

This section is for maintenance personnel only, enter password to access the sub-menu as guided by Chapter 6.2.4.

The sub-menu:

No.	Display	Explanation
1	ALL Set Enable	To enable the setting-up of some functions under the menu of Technical Set
2	Standard Set	To set up safety standard or country grid code for the inverters
3	Rated VAC Set	To set up the rated voltage
4	VAC H Limit	To set up the high limit of AC output voltage
5	VAC L Limit	To set up the low limit of AC output voltage
6	Pmax Limit	To set up the max generation power
7	AC Inst Limit	To set up the AC instant voltage limit

8	Power Control	To set up the power control
9	Standard Func	To set up the increase power rate limit and decrease power rate limit
10	Special Func	To set up special functions
11	Set Passwords	To set up passwords
12	Factory Reset	To restore factory settings
13	Adjust Total E	To adjust the total power generated
14	Reset Total E	To clear the power generation record
15	Export ON/OFF	To enable the grid connection
16	Export Limit	To set up export power limit

Press UP/DOWN to scroll the menu, press ENT to access the sub-menu, and press ESC to return to the previous menu.



NOTE: This part is accessible for qualified and accredited technicians only!

6.2.5.1 All Set Enable

This function is to enable some of the setting-up functions under the menu of 'Technical Set'. Before enabling or setting up some of the function under this menu, please turn the 'All Set Enable' on. The functions need ALL SET Enable include:

1. VAC H_Limit/VAC L_Limit; 2. Standard Function; 3. Pt Vol High/Low; 4. Special Function: HVRT, LVRT, Buzzer Enabled, Relay Check.

ALL SET Enable
ON

6.2.5.2 Standards Set

The safety standard for different countries can be selected in this sub-menu.

Standard Set
cEN50549_1

Countries of European Union grid codes can be selected here.

Procedures:

Step1: go to 'All Set Enable' in the menu of 'TECHNICAL SET' and turn the status to 'ON'.

Step2: move to 'Standard Set' and get inside

Step3: select the country grid code needed.

Press UP/DOWN to scroll through the national standards, press ENT to confirm the safety standard, and press ESC to return to the previous menu.



NOTE: This operation is for maintenance personnel only. Password is required to access this part!

6.2.5.3 Rated VAC Set

Rated AC output voltage can be set up here. Only when there are more than one type of applicable voltage will this function be used.

6.2.5.4 AC Output Voltage Limit

This section is to set up the high and low limit of AC output voltage as permitted by local grid company if the grid voltage is beyond the range specified by national standards.

VAC	H	Limit	Set
270V			

VAC	L	Limit	Set
180V			

The detailed procedure is described in a separated document named 'Voltage Adjustment'.

6.2.5.5 AC Output Frequency Limit

This section is to set up the high and low limit of AC output frequency as permitted by local grid company if the grid frequency is beyond the range specified by national standards.

FAC	H	Limit	Set
52Hz			

FAC	L	Limit	Set
47Hz			

The method to set up the AC output frequency limit is similar to that of AC voltage adjustment.

6.2.5.6 Max Generation Power Setup

The max output power can be set up here.

Pmax	Limit
70% of Prated	

The detailed procedure to set up the Max generation power is described in a separated document named 'Power Generation Limit'.



NOTE: The inverter has generation limit control capability which has yet to been tested according to EN 50549-10:2022.

6.2.5.7 Power Control

No.	LCD Display	Explanation
1	Q Set +60%	To set up reactive power
2	PF Set +80%	To set up power factor
3	Q Reset YES=ENT EXIT=ESC Are You Sure?	To restore reactive power
4	PR Reset YES=ENT EXIT=ESC Are You Sure ?	To restore power factor

Reactive power and power factor can be set up and restored here.

The power quality response modes as required by the standard of EN 50549-10:2022 can be activated or controlled under this menu combined with the menu of special function. The detail procedure will be described in the following part.

6.2.5.8 Standard Function

Power increase slope and decrease slope can be set up here.

Pwr UpSlope
90%

Pwr DownSlope
20%

This part is for the setup of power rate limit modes as required by EN 50549-10:2022. Soft ramp up after connect, reconnect or soft ramp up/down

following a response to frequency disturbance is available in those inverters.

Procedures to set up the gradient of power rate limit:

Step1: Go to 'All Set Enable' in the menu of 'TECHNICAL SET' and turn the status to 'ON'.

Step2: Go to 'Standard Func' and then get inside.

Step3: Go to set up the 'Pwr UpSlope' or 'Pwr DownSlope' for the soft ramp up/down of rated power per minute.



NOTE: This operation is for maintenance personnel only. Password is required to access this part!

6.2.5.9 Special Function Setup

No.	LCD Display	Explanation
1	Set CV MPPT	To set up the constant PV voltage
2	All PV Paral	To set up the multiple MPPTs parallel mode
3	HVRT	To enable the High Voltage Ride Through
4	LVRT	To enable the Low Voltage Ride Through
5	1/2BUS Prot	To enable the bus mid-point voltage protection
6	DCI Prot	To enable the DC component inspection

7	GFCI Prot	To enable the GFCI protection
8	ISO Prot	To enable the ISO protection
9	Island Prot	To enable the island protection
10	Buzzer Enabled	To enable the buzzer
11	Relay Check	To enable the relay
12	QU CURVE	To enable the QU curve
13	PF CURVE	To enable the PF curve
14	Q CURVE	To enable the Q curve
15	PU CURVE	To enable the PU curve
16	Shadow MPPT:	To enable the shadow MPPT mode

17	Pt Fre High 3	To set up the over frequency protection 3
18	Pt Fre High 2	To set up the over frequency protection 2
19	Pt Fre High 1	To set up the over frequency protection 1
20	Pt Fre Low 1	To set up the under frequency protection 1
21	Pt Fre Low 2	To set up the under frequency protection 2
22	Pt Fre Low 3	To set up the under frequency protection 3
23	Pt F recover H	Over frequency protection recovery
24	Pt F recover L	Under frequency protection recovery
25	Pt Vol High 3	To set up over voltage protection 3
26	Pt Vol High 2	To set up over voltage protection 2

27	Pt Vol High 1	To set up over voltage protection 1
28	Pt Vol Low 1	To set up under voltage protection 1
29	Pt Vol Low 2	To set up under voltage protection 2
30	Pt Vol Low 3	To set up under voltage protection 3
31	Pt V Recover H	Over voltage protection recovery
32	Pt V Recover L	Under voltage protection recovery
33	10Min OV set	To set up 10 minute over voltage protection

6.2.5.9.1 Island Protection


The active anti-islanding protection of the inverters is achieved by shifting the frequency of the inverter away from nominal conditions in the absence of a reference frequency (frequency shift). It is enabled by default.

6.2.5.9.2 Volt-var Response Mode

QU CURVE ON

The QU Curve is enabled by default. The volt-var response mode changes

the reactive power absorbed or supplied by the inverter in response to the voltage at its grid-interactive port. The diagram and table below are the response mode required for the volt-var response according to the standard of EN 50549-10:2022.



Q(U)additional parameter configuration

Parameter	Setting(a)	Setting(b)
Time constant	As fast as possible but not slower than 3 s	As slow as possible but not slower than 20 s
Min cos ϕ	0,4	Deactivated
Lock-in power	Deactivated	20 % P_{na}
Lock-out power	Deactivated	5 % P_{nb}
a or minimum regulation level +20% P whichever is higher b or minimum regulation level +5% P whichever is higher		

Procedures to enable or disable the Volt-var Response Mode:

Step1: go to 'All Set Enable' in the menu of 'TECHNICAL SET' and turn the status to 'ON'.

Step2: go to 'Special Func' and then go to 'QU Curve'

Step3: enable or disable the 'Volt-var Response Mode' by changing the status to 'ON' or 'OFF'.




NOTE: This operation is for maintenance personnel only. Password is required to access this part!

6.2.5.9.3 Volt-watt Response Mode

PU CURVE ON

The PU Curve is enabled by default. The volt-watt response mode varies the maximum active power output level of the inverter in response to the voltage at its grid-interactive port. The diagram below is the response curve required for the volt–watt response according to the standard of EN 50549-10:2022.



(P)Optional additional parameter configuration if applicable

Parameter	Setting(a)	Setting(b)
Lock-in voltage	Deactivated	105 %Un
Lock-out voltage	Deactivated	100 %Un

Procedures to enable or disable the Volt-watt Response Mode:

Step1: go to 'All Set Enable' in the menu of 'TECHNICAL SET' and turn the status to 'ON'.

Step2: go to 'Special Func' and then go to 'PU Curve'

Step3: enable or disable the 'Volt-watt Response Mode' by changing the status to 'ON' or 'OFF'.



NOTE: This operation is for maintenance personnel only. Password is required to access this part!

6.2.5.9.4 Fixed Power Factor Mode or the Reactive Power Mode

PF CURVE OFF

Q CURVE OFF

Those modes are disabled by default. The fixed power factor mode or the reactive power mode may be enabled in some situations by the electrical distributor to meet local grid requirements, one of these modes shall be enabled if the volt-var mode is disabled.

Procedures to set up the Reactive Power Mode:

Step1: go to 'All Set Enable' in the menu of 'TECHNICAL SET' and turn the status to 'ON'.

Step2: go to 'Special Func', then go to 'Q Curve' and enable the Q Curve by change the status to 'ON'

Step3: go to 'Power Control' and then go to 'Q Set'.

Step 4: Set up the Reactive Power Mode manually.

Procedures to set up the Fixed Power Factor Mode:

Step1: go to 'All Set Enable' in the menu of 'TECHNICAL SET' and turn the

status to 'ON'.

Step2: go to 'Special Func', then go to 'PF Curve' and enable the PF Curve by change the status to 'ON'

Step3: go to 'Power Control' and then go to 'PF Set'.

Step 4: Set up the Fixed Power Factor manually.



NOTE: This operation is for maintenance personnel only. Password is required to access this part!

6.2.5.10 Password Set-up

The password for 'Detail Info' and 'Technical Set' can be reset here.

Password:	1000
Confirm:	1000

Press ENT to move the cursor, press UP/DOWN to select a number for a digit selected, and press ENT to confirm the setup after the last digit has been set up. Press ESC to return to previous menu.

6.2.5.11 Factory Reset

This function is designed to restore factory defaults.

YES=ENT	EXIT=ESC
Are You Sure ?	

6.2.5.12 Adjust Total E

The total energy generated may be cleared or changed after maintenance or translocation, and the previous data can be restored with this function. The total energy generated can be adjusted here.

TOTAL	ENERGY
5700000 KWh	

6.2.5.13 Reset Total E


The total energy generated record can be cleared here, and after clearing, the energy generation record will be zero.

YES=ENT	EXIT=ESC
Are You Sure?	

Press ENT to clear the energy generation history and press ESC to cancel the previous operation.


6.2.5.14 Export On/Off

This function is to control the grid connection or disconnection of inverters.



Press UP/DOWN to scroll the menu, press ENT to perform the selection, and press ESC to return to the previous menu.

6.2.5.15 Export Limit



The inverter's export limit can be achieved together with external devices such as a CT or meter. There are two types of limit, soft limit and hard limit. The soft limit means that the limit is controlled by software, and hard limit means that if the generation exceeds the limit, the inverter will stop working. Under the detection mode menu, you can choose CT mode or meter mode. For the normal working of inverters, please use the soft limit only. The hard limit is used only by compulsory requirement of local grid companies.

7. Maintenance and Troubleshooting

7.1 General Maintenance

The Inverters do not need regular maintenance and just ensure that they are free of dust, foliage and other dirt.



NOTE: The use of cleaning agents may damage the machine and its components. Only use a cloth moistened with clear water to clean the machine.

7.2 Disposing of Inverters

If the inverters need to be disposed of, please do that according to the local regulations for electrical equipment waste, and choose the right site for the disposing specified for electrical equipment waste according to local regulations.

7.3 Storage and Transportation

If the inverters will not be installed in a short term, please store them in a dry room with the ambient temperature between $-25\sim 60\text{ }^{\circ}\text{C}$. For storage and transportation, please pack them in the original package if possible and stack inverters no more than 6 packs.

7.4 Troubleshooting

No.	Events	Explanation	Solutions
1	DC Volt Over	High voltage of PV input strings	1. Check if the input voltage exceeds the inverter's upper limit of input voltage 2. Decrease solar panels quantity in series
2	DC Over Current Soft	PV current exceeds the software protection limit	1. Restart the inverter 2. Decrease solar panels quantity in parallel if it occurs repeatedly
3	DC Over Current Hard	PV current exceeds the hardware protection limit	1. Restart the inverter 2. Decrease solar panels quantity in parallel if it occurs repeatedly
4	Bus Over Voltage Soft	Transient bus voltage exceeds the software protection limit	1. Check if the input voltage exceeds the inverter's upper limit of input voltage 2. If not, restart the inverter 3. If yes, decrease solar panel quantity in series
5	Bus Over Voltage Hard	Transient bus voltage exceeds the hardware protection limit	1. Check if the input voltage exceeds the inverter's upper limit of input voltage 2. If not, restart the inverter 3. If yes, decrease solar panel quantity in series

6	Transient Over Voltage	Transient over voltage in grid	Restart the inverters
7	Inv Over Current Soft	Inverter software over current	1. Restart inverters 2. Decrease string in parallel
8	Inv Over Current Hard	Inverter hardware over current	1. Restart inverters 2. Decrease string in parallel
9	Island Protect	Island effect protection	1. Check whether AC circuit breaker has been triggered off 2. Check AC cables connection 3. Check whether grid is not in service 4. If the above reasons have been excluded and this fault still occurs in the LCD screen, contact the installer
10	Low Temperature Inside Inverters	Low Temperature Inside Inverters	Check if the ambient temperature is below normal working temperature of inverters and increase ambient temperature
11	High Temperature Inside Inverters	High temperature inside inverters	1. Check the ventilation of installation environment 2. Avoid direct sunlight
12	Extern Flash	Abnormality in external flash reading and writing	Restart the inverter

13	Bus Unbalance	Bus Unbalance	Restart the inverter
14	Low bus voltage	Low bus voltage	1. Check if the input voltage is too low 2. If not, restart the inverter 3. If yes, increase solar panel quantity in series
15	Over Frequency	Export reduction due to over frequency	Adjust the protection value limit by user-designing function as permitted by grid company
16	Over Temperature	Export reduction due to over temperature	1. Check the ventilation of installation environment 2. Avoid direct sunlight
17	GFCI Device Fault	Fault in current leakage testing device	Restart the inverter or contact the installer
18	ACHCT Device Fault	Fault in HCT device on AC side	Restart inverter or contact the installer
19	GFCI Out Range	Current leakage is out of range	Check the AC connection and DC connection, and check internal wire connection

20	DCI Out Range	DC component is too large	Restart the inverter or contact the installer
21	ISO Out Range	The insulation impedance is too small	1. Remove all DC inputs, reconnect them one by one, and restart the inverter 2. Identify the string that causes the fault and check the insulation of the string
22	No Grid... Pls Turn On AC	No utility grid	1. Check the AC breaker 2. Check the connection of AC plug 3. Check whether the inverter's L, N, PE line have been connect with the corresponding grid L, N, E line correctly
23	Temp is Too High	Temperature is too high	1. Check the ventilation of installation environment 2. Avoid direct sunlight
24	Temp is Too Low	Temperature is too low	Check if the ambient temperature is below normal working temperature of inverters and increase ambient temperature
25	PV Over Voltage	Over voltage in PV Inputs	1. Check if the input voltage exceeds the inverter's upper limit of input voltage. 2. Decrease solar panel quantity in series

26	Grid Volt Over 110%	The grid is overloaded by 10% for over 10 minute	1. Wait for the inverter to recovery 2. If the impedance of AC cable is too small, replace it with a larger size cable 3. Adjust the protection value limit as permitted by the grid company
27	Grid Volt Out Range	Grid voltage is out of range	1. If the impedance of AC cable is too small, replace it with a larger size cable 2. Adjust the protection value limit as permitted by the grid company
28	Grid Freq Out Range	Grid frequency is out of range	Adjust the protection value limit through self-designing function as permitted by the grid company
29	Relay Fault	Fault in grid-connection relay	Restart the inverter or contact the installer
30	MS Comm Fault	Communication fault between the main CPU and the slave CPU	Restart the inverter or contact the installer
31	Power to Grid beyond Limit	Power exported to Grid exceeds the Hardware Limit	1. Turn on the software limit and set up a software limit that is lower than the hardware limit

			2. Turn off the hardware limit if permitted
32	PEN No Connect	Grounding fault as the PE and N line has not been connected well	1. Check the connection of the PE line and the N line 2. Contact the installer

**NOTE**

If any event in the above table is displayed, please turn off the inverter, wait 5 minutes and then restart the inverter.

8. Specification

Model	CE-3P40KEG	CE-3P50KEG	CE-3P60KEG
DC Input			
Recommended max. PV power	60KW	75KW	90KW
Max. input voltage	1100 V		
Start-up voltage	50 V/40 V		
MPPT voltage range	100V~1080 V		
Max. input current	4*40A	5*40A	6*40A
Max. short circuit current	4*60A	5*60A	6*60A
MPPT number	4	5	6
String	2/8	2/10	2/12
AC Output			
Rated Output Power	40KW	50KW	60KW
Max. apparent output power	40KVA	50KVA	60KVA
Max. active power	40KW	50KW	60KW
Rated grid output current	58.0A	72.5A	87.0A
Max. output current	58.0A	72.5A	87.0A
Rated grid voltage/range (3P/N/PE)	220V/380V, 230V/400V, 240V/415V, 312~520		
Rated grid frequency	50/60 Hz		
Power Factor	>0.99, 0.8 leading ~ 0.8 lagging		
THDi	<3%		
Efficiency			
Max. efficiency	98.80%		
EU efficiency	98.30%		
Protection			
Ground fault monitoring	Yes		
Output over voltage protection	Yes		
Anti-Islanding Protection	Yes		
Integrated AFCI	Optional		
DC reverse-polarity protection	Yes		
Over voltage category	AC Class III/PV Class II		
General Data			
Dimension (W*H*D)	700*519*270 mm		
Shell material	Aluminium alloy		
Noise Emission	≤ 40 dB(A)		
Weight	45kg		
Operating ambient temperature range	-25~60 °C(>45°C derating)		
Topology	Transformerless		
Ingress protection	IP66		
Cooling concept	Smart Fan & Natural Convection		
Max. operation altitude	3000 m		
Country of manufacturing	China		
Grid connection standard	AS/NZS4777:2020, EN50549-10:2022, G98:2021, G99:2021, NC RFG, ABNT NBR 16150, VDE-AR-N 4105, CEI0-21, CEI0-16, RD1699, NA/VEEA, C10:2019, PPDS:2021, Tor+R25, IEC61683, IEC61727&62161		
Safety/EMC standard	IEC-62109-1/-2, IEC-61000-1/-2/-3, NB/T32004		
DC connection	MC4/D4		
Communications	WiFi(2.4G), GPRS, 4G, Bluetooth, RS485		

Zhejiang Chisage New Energy Technology Co., Ltd.

 Tel: +86 150 5749 1826

 Email: info@chisagess.com

 Web: www.chisagess.com

 Add: No.1828, Fuqing South Road, Panhuo Street, Yinzhou District, Ningbo City,
Zhejiang Province, China 315000
