


User Manual

Hybrid Inverter
Plu-5/6/6.6G1-LE



CHISAGE ESS

www.chisagess.com

Contents

Cautions.....	1
1 General Introduction	2
1.1 Brief Description.....	2
1.2 Product Features.....	2
1.3 Product Appearance Introduction.....	3
1.4 Product Size	4
1.5 System structure.....	4
1.6 Inverter parameter	5
2 Installation Instructions	6
2.1 Installation preparation	6
2.1.1 Installation Notes Reiterated.....	6
2.1.2 Installation environment, space requirements.....	6
2.1.3 Installation tool preparation	7
2.1.4 Inspection of out-of-box accessories.....	7
2.2 Introduction of equipment terminal	10
2.3 Wall mount.....	11
2.4 Battery wiring work	12
2.4.1 Battery Power Cable Wiring	12
2.4.2 Battery communication cable connection	13
2.5 Power grid, load, GEN wiring	13
2.6 Photovoltaic wiring	14
2.7 CT wiring	16
2.8 Meter connection.....	17
2.9 Ground connection.....	18
2.10 WIFI connection	18
2.11 Stand-alone operation system diagram	18
3 Display and setup	19
3.1 Run data display instructions	19
3.1.1 Photovoltaic data.....	21
3.1.2 Battery data	22
3.1.3 Inverter data	23
3.1.4 Grid data.....	23
3.1.5 Load data.....	24
3.2 Run parameter setting	24
3.2.1 Battery parameter setting	24
3.2.2 Grid parameter setting.....	26
3.2.3 GEN port function settings	27
3.2.4 CT transformation ratio setting	28

3.2.5 Operating Mode Settings	29
3.2.6 System Setup.....	29
3.3 Events Display And Device Info.....	31
4 Operation and maintenance.....	32
4.1 Trial run.....	32
4.2 Stand-alone operation and logic description.....	32
4.3 Parallel operation and logical explanation	33
4.3.1 Set entry path description.....	33
4.3.2 Parallel operation logic	33
4.3.3 Parallel system wiring diagram.....	34
4.4 Example of five parallel inverter on grid	37
4.4.1 Grid and load connection	37
4.4.2 Parallel cable connection and check	37
4.4.3 ON-Grid startup parallel	39
4.4.4 Off-grid startup parallel.....	39
4.4.5 Shut down the Inverter.....	40
4.5 Fault alarm and handling.....	40
4.6 Product routine maintenance suggestions	45
4.6.1 Routine inspection.....	45
4.6.2 Monthly inspection	45
4.6.3 Quarterly inspection.....	45
5 Transportation and storage	46
5.1 Product Shipping Requirements.....	46
5.1.1 Logistics.....	46
5.1.2 Unloading and handling.....	46
5.2 Product storage environment requirements.....	46
6 Legal Notices.....	47
7 Attachments	48
Attachments 1 Network port definition description.....	48
Attachments 2 CT size and model	50
Attachments 3 Hybrid Inverter data.....	51

Cautions

- Before using this product, please read the instruction manual carefully.
- Non-professionals should not disassemble the machine, wrong reassembly may cause electric shock or fire. If you need maintenance or repair, please contact the after-sales service center.
- For your safety, please disconnect all power and cables of this equipment before maintenance or cleaning.
- Note: Non-professionals are not allowed to install this device and battery.
- In order to ensure the best working condition of this device, please select the appropriate cable size correctly.
- Please try to avoid using metal tools near the battery. If you must use it, please be careful. Dropping the tool may cause sparks or short circuits on the battery or other electrical components, or even cause an explosion.
- When disconnecting the AC or DC terminals, please strictly follow the installation steps. For details, please refer to the "Installation" section of this manual.
- Grounding Instructions - This equipment should be connected to a permanently grounded wiring system. Be sure to follow local requirements and regulations when installing this equipment.
- Do not short-circuit the AC output and DC input, and do not connect to the mains when short-circuited.
- The surface temperature of the inverter is relatively high during operation. Please do not touch the inverter case.

1 General Introduction

This manual mainly introduces product information, functional operation, equipment installation and maintenance guidelines. This brochure does not cover all information related to photovoltaics.

1.1 Brief Description

The hybrid inverter intergrate PV power generation and energy storage, it focuses on providing high power generation and stable power supply. It is designed according to market requirements of residential and industrial hybrid systems. It not only can be used in self-consumption hybrid system, but also be used for battery back system. To meet different conditions, it can work at on-grid and off-grid condition. You can parallel more inverters to meet industrial system requirements.

1.2 Product Features

The hybrid inverter adopts advanced digital control technology, which optimizes the control performance and improves the reliability of the system. The inverter features as below:

- Intelligent management system and a variety of working modes to meet different customer needs.
- Strong scalability. Support different power inverters parallel, support a maximum of 20 inverters parallel operation.
- Supports on/off-grid work mode switching. Strong overload capability. 110% overload can run for 2 hours. 100% unbalanced load is supported
- Installed a touch color screen. It also supports computers, mobile phones or Internet for remote monitoring, operation and upgrades. The operating information such as inverter and battery mode can be set on the touch screen.
- Protection class IP65. Light weight, small size. Easy to install.
- Two MPPT, flexible module configuration.
- Independent AC input interface for diesel generators. Support storage of energy from diesel generators.
- With intelligent load or AC coupling device interface. Suitable for a variety of scenarios.
- With photovoltaic input lightning protection.
- With reactive power regulation function.
- Supports overtemperature, overcurrent, and short circuit protection. Supports anti-island protection and other protection functions. Ensure the safe, stable and reliable operation of the system.

1.3 Product Appearance Introduction

The appearance of this product and its various descriptions are shown in Figure 1.1 and Table 1.1 below.





Figure 1.1 Overview of Hybrid Inverter Appearance

Table 1.1 Description of product components

1	Indicator light	7	Meter-485 interface	13	Gen interface
2	LCD display screen	8	Parallel communication interface	14	PV input interface
3	Function buttons	9	CT and other port	15	WIFI interface
4	Battery forced start button	10	BMS interface		
5	Battery input interface	11	Grid interface		
6	MODBUS interface	12	Load interface		

1.4 Product Size



- Size W*H*D mm : 305x450x165
- Weight kg : 14.8

1.5 System structure

As shown in Figure 1.2, it shows the basic application of the hybrid inverter, and its complete operating system also includes: diesel generators, power grids, and photovoltaic modules.

Depending on your requirements, other possible system architectures are available from your system integrator. The device can power a variety of appliances in a home or office environment, including motor-type appliances such as refrigerators and air conditioners.

ON/OFF GRID SOLAR HYBRID HOME SYSTEM




Figure 1.2 Complete operation system of hybrid inverter

1.6 Inverter parameter

The detailed technical specifications of this equipment are detailed in the annex 3.

2 Installation Instructions

2.1 Installation preparation

2.1.1 Installation Notes Reiterated

This device is designed for outdoor use IP65 , please ensure that the installation site meets the following conditions:

- out of direct sunlight.
- Not in areas where highly flammable materials are stored.
- Not in potentially explosive area.
- Do not expose directly to cold air.
- Keep away from TV antennas or antenna cables.

2.1.2 Installation environment, space requirements

To ensure the normal operation of the hybrid inverter, please install the equipment in a controlled environment. At the same time, in order to avoid overheating of the hybrid inverter, please keep the device ventilated smoothly. The ventilation holes and fans must not be blocked by sundries. The installation site must meet the following conditions:

- 1 Close to the power supply, easy to distribute power.
- 2 Clean and dust-free environment.
- 3 The altitude does not exceed 2000m, If exceeded, it shall be derated according to relevant national standards.
- 4 The ambient temperature is $-40\sim 60^{\circ}\text{C}$.
- 5 No corrosive, explosive and insulating gas and conductive dust, and keep away from heat sources.
- 6 No vibration and bumps, and the vertical inclination does not exceed 5%.
- 7 If the hybrid inverter operates in an air-conditioned environment around 20°C , it will improve reliability and prolong service life.

Consider the following points before choosing an installation location:

- For installation, please choose a vertical wall with strong load-bearing capacity, suitable for installation.
- On concrete or other non-flammable surfaces.
- Install this inverter at the line of sight level so that the LCD display can be read at any time.
- The ambient temperature should be between -40°C and 60°C to ensure the best operation.
- Please install the equipment in a position with sufficient distance reserved, as shown in figure

2.1 to ensure sufficient heat dissipation and enough space to remove the cable. For proper air circulation to dissipate heat, leave a gap of approximately 1000mm. Lateral 500mm, upper and lower 500mm, and anterior outflow of 1000mm.



Figure 2.1 recommended reserved distance around the equipment

2.1.3 Installation tool preparation

Phillips screwdriver specification: PH2, moderate length, diameter 5.5mm, 10mm, 13mm wrench or sleeve for M3, M6, M8 outer hexagon screws

2.1.4 Inspection of out-of-box accessories

Please check the equipment before installation. Please make sure that there is no damage to the packing. The package you receive should include the items in Table 2.1, as shown in figure 2.2 below.

Table 2.1 Product list details

Serial number	Item name/specification	Quantity	Remarks
1	Inverter this equipment	1	
2	User manual	1	Place it in the box
3	Shipment inspection report	1	
4	Hardware/screws/stainless steel built-in expansion screws, hexagonal internal expansion bolts, M8*80	4	For securing the chassis
5	Quick Installation Guide	1	
6	Wi-Fi Antenna	1	
7	Current sensor/ AKH-0.66 K- ϕ 16 100A/50mA	1	Optional
8	Communication cable/Cat5e super 5 category 5 finished network cable 2 meters long	1	Optional
9	CAN parallel wire/twisted pair shielded wire 2m	1	For parallel operation (Optional)
10	PV input connector/MC4/line end female end/H4CFD2TMS/nut with pin	2	
11	PV input connector/MC4/line-end male/H4CMD2TMS/nut with pin	2	
12	Smart Meter/ SDM230	1	Optional
13	Battery Temperature Sensor/NTC Temperature Sensor B3950 10K thermistor, stainless steel waterproof probe 3 meters long	1	Optional
14	Certificate	1	
15	Warranty card	1	
16	PE transparent bag/transparent ziplock bag (small)	3	Assembly accessories, accessories, etc
17	PE transparent bag/transparent ziplock bag (large)	2	user manual, etc.
18	Excipients / environmental protection / desiccant / 5g / pack	1	Packed in a box








 <p>Hybrid Inverter X1</p>	<p>User manual</p> <p>User manual X1</p>	<p>Shipment inspection report</p> <p>Shipment inspection report X1</p>	<p>Certificate of approval</p> <p>Certificate of approval X1</p>
<p>Warranty Card</p> <p>Warranty Card X1</p>	<p>Quick Install Guide</p> <p>Quick Install Guide X1</p>	 <p>Stainless steel anti-collision bolt M8X80 X4</p>	 <p>Desiccant ×1</p>
 <p>PV input connector/MC4 line end male/H4CMD2TMS/with pin nut X2</p>	 <p>PV input connector/MC4 line end female/H4CFD2TMS/with pin nut X2</p>	 <p>Wi-Fi Antenna X1</p>	 <p>Communication cable X 2m (Optional)</p>
 <p>(For parallel Optional) Can parallel line X 2m</p>	 <p>NTC Battery Temperature Sensor (Optional) X1</p>	 <p>(Optional) Sensor Clamp X1</p>	 <p>(Optional) Smart Meter X1</p>
 <p>Self-sealing bags (small) ×3</p>	 <p>Self-sealing bags (big) ×2</p>		

Figure 2.2 Product list details

2.2 Introduction of equipment terminal

The function of the keys near the LCD is shown in figure 2.3. The function of the connection socket and through hole at the bottom of the equipment is shown in figure 2.4. The internal and external interface board of the equipment is shown in figure 2.5.




Figure 2.3 key definition near LCD




Figure 2.4 definition of socket terminal at the bottom of the device




Figure 2.5 schematic diagram of internal and external interface board of equipment
Terminal functional definitions are detailed in Appendix 1

2.3 Wall mount

Warm reminder, the equipment is very heavy, please take it out carefully!

- Move the device and hold it, ensuring that the inverter is close to and perpendicular to the wall. Mark the installation wall according to the dimensions of the four bolts in the middle of the wall mount (343X350mm).
- Select the recommended drill bit as shown in figure 2.6 below to drill 4 holes in the wall with a depth of 52-60 mm.
- Use a suitable hammer to insert the expansion housing into the holes (expansion screws need to be installed in all four holes shown in the picture), align the inverter with the wall mount holes on the side of the inverter, hang the inverter, and tighten the screw heads of the expansion bolts to complete the installation.




Fig. 2.6 schematic diagram of borehole location

2.4 Battery wiring work

For safe operation and compliance, a separate DC circuit breaker is required between the battery and the equipment. In some applications, switchgear may not be required, but circuit breakers still need to be disconnected. For the required fuse or circuit breaker specifications, please refer to the typical data selection in Table 2.2 below.

2.4.1 Battery Power Cable Wiring

For your safety and efficient operation of the equipment, please connect the battery with a suitable cable to reduce the risk of injury. You can also refer to the recommended cable shown in Table 2.2.

Table 2.2 Recommended cable example

	Rated Power	Cable size	Cable size mm ²	Torque value
Bat side	6kW	2AWG	35	12.0Nm
	5 kW	2AWG	35	12.0Nm
	4 kW	6AWG	16	12.0Nm
	3 kW	6AWG	16	12.0Nm
	Rated Power	Cable size	Cable size mm ²	Beeaker Current
AC side	6 kW	10AWG	6	40A
	5 kW	12AWG	4	30A
	4 kW	12AWG	4	30A
	3 kW	12AWG	4	30A



All wiring must be carried out by professionals!

Please select the appropriate battery cable and bolt, find the "Battery end hole" in the schematic diagram of "Figure 2.4 Definition Diagram of Socket Terminal at the Bottom of Equipment", and insert the cable into the correct through hole. Tips: Please pay attention to the positive +, negative - corresponding wiring Use a suitable screwdriver to unscrew the bolt, install the battery cable terminal, and then use the screwdriver to tighten the bolt to ensure that the bolt is tightened, the torque is 12.0Nm, clockwise, to ensure that the polarity of the battery and inverter is correctly connected. Before making the final DC connection or closing/disconnecting the DC breaker, make sure that the battery positive + must be connected to the inverter positive + and the battery negative - must be connected to the inverter negative - . Reversed battery connections can damage the device.




Figure 2.7 Schematic diagram of battery communication connection

2.4.2 Battery communication cable connection

As shown in Figure 2.8, connect the BMS of BAT_PACK to the BMS network port of the device in the figure. The definition of the communication connection line is shown in Table 2.2. (In the actual wiring process, the BMS communication line and the battery line need to be routed from the corresponding ports. This schematic diagram is only used to illustrate the specific location of the wiring position.)

2.5 Power grid, load, GEN wiring

Before connecting to the grid, please install a separate AC circuit breaker between the device and the grid. In addition, it is recommended to install an AC circuit breaker between the standby load and the device. This ensures that the inverter can be safely disconnected during maintenance and fully protected from overcurrent. The recommended cable size and circuit breaker current are shown in Table 2.2.

There are three terminal blocks marked with "Grid", "Load" and "GEN". Please do not connect the input and output connectors by mistake. In addition, the GEN port can be connected to the generator, smart load or AC coupling unit (grid-connected inverter). After the actual wiring is completed, you need to set the corresponding interface type on the LCD. For details on the setting method, please refer to Chapter 3, Section 3.2.3 Generator Port Function Setting.

All wiring must be performed by qualified personnel. Using the appropriate cable for AC input connection is very important for the safe and efficient operation of the system. To reduce the risk of injury, please use the correct recommended cable as shown in Figure 2.9 below.



Please make sure that the AC side power supply is open before connecting.




Figure 2.8 connection of power grid, load and generator

Follow these steps to connect the Grid grid, Load load, and Gen generator ports:

- Be sure to turn off the AC circuit breaker or isolation switch before connecting the power grid, load, and generator.
- Remove the 10mm long insulating sleeve, unscrew the bolts, insert the wire according to the polarity marked on the terminal, and tighten the wiring screw. Make sure the connection is complete.
- Then insert the AC output wire according to the polarity marked on the terminal and tighten the terminal. Be sure to connect the corresponding N and PE wires to the relevant terminals to ensure that the wires are firmly connected.
- Electrical appliances such as air conditioners need at least 2-3 minutes to restart because they need enough time to balance the refrigerant gas in the loop. If a power shortage occurs and recovers within a short period of time, it will cause damage to the equipment you are connected to. To prevent such damage, check whether the air conditioner manufacturer is equipped with a delay function before installation. Otherwise, this equipment will trigger an overload failure and cut off the output to protect your equipment, but sometimes it will still cause internal damage to the air conditioner.

2.6 Photovoltaic wiring

Before connecting the photovoltaic module, install a separate DC circuit breaker between the device and the photovoltaic assembly. Connecting photovoltaic modules with appropriate cables is very important for the safe and efficient operation of the system. To reduce the risk of injury, the recommended cable size is 12AWG, each 4mm² cable.

To avoid any failure, do not connect any photovoltaic module that may leakage current. For example, a grounded photovoltaic module can cause current leakage to the device. Photovoltaic junction boxes with surge protection are required. Otherwise, when the photovoltaic module is struck by lightning, the equipment will be damaged.



When using PV modules, please ensure the PV+ & PV- of solar panel is not connected to the system ground bar.

- Photovoltaic module selection guide: When selecting suitable photovoltaic modules, please be sure to consider the following parameters as shown in Table 2.3:
 1. The open circuit voltage (Voc) of the photovoltaic module does not exceed the maximum open circuit voltage of the hybrid inverter.
 2. The open circuit voltage (Voc) of the photovoltaic module should be higher than the minimum starting voltage of the hybrid inverter.

Table 2.3 description of photovoltaic module selection

Item	5kW	6kW	6.6kW
PV Input Voltage	370V(125V~500V)		
MPPT Range	150V~425V		
No. of MPPT Tracker	2		
No. of String Per MPPT Tracker	1+1	1+1	1+1

- Photovoltaic module wiring
 - 1 Turn off the main AC circuit breaker of the power grid.
 - 2 Close the DC circuit breaker.
 - 3 Assemble the photovoltaic input connector as shown in Figure 2.9 at the bottom of the device.



Safety tips: Do not ground the positive or negative electrode of the photovoltaic panel device, otherwise it will seriously damage the inverter.



Safety tip: Before connecting, please ensure that the polarity of the output voltage of the photovoltaic panel device is consistent with the "DC+" and "DC-" symbols.



Safety tip: Select a qualified DC cable: 4~6 mm² 12~10AWG single cable .
 Safety tip: Before connecting the inverter, ensure that the open circuit voltage of the photovoltaic panel device is within 500V





Figure 2.9 Photovoltaic input connector: DC+ connector left DC-Connector right

● The steps for assembling DC connectors are as follows:

1. Peel off the DC line about 7mm and remove the connector cover nut see figure 2.10 .




Figure 2.10 Connector cover nut

2. Crimp the metal terminal with crimping pliers, as shown in figure 2.11.




Figure 2.11 Crimping clamp crimping metal terminal

3. Insert the Contact pin into the top of the connector and screw the cover nut to the top of the connector. figure 2.12 .

4. Finally, insert the photovoltaic DC connector into the positive and negative input of the Hybrid inverter, as shown in figure 2.13.




Figure 2.12 Stylus inserted into the top of the connector




Figure 2.13 The DC connector is inserted into the positive and negative input of the hybrid inverter equipment.



Warning: sunlight on the panel will generate voltage, high voltage series may be life-threatening. Therefore, before connecting the photovoltaic DC input line, the solar panels need to be blocked by opaque materials, and the DC switch should be turned off, otherwise the high voltage of the equipment may be life-threatening.

2.7 CT wiring

In the power grid cable, as shown in figure 2.14, The single-phase current transformer are passed through the live wire, the direction arrow of the transformer faces the equipment side, and the transformer sampling line reaches the internal interface board J19 sampling terminal through the

equipment COM3 through hole. At the same time, the J19 terminal is connected to the battery temperature sampling signal line.

For detailed CT specifications, please refer to Appendix 2.




Figure 2.14 schematic diagram of external CT wiring and battery temperature sampling wiring

2.8 Meter connection

As shown in figure. 2.15 Meter wiring diagram. The solid line on the left indicates that the SDM230 is connected.




Fig. 2.15 Meter wiring diagram

2.9 Ground connection

To prevent electric shock, connect the ground cable on the power grid side to the inverter. Fasten the bottom line in the "ground" bolt hole as shown in Figure 2.16 ⊕.




Fig. 2.16 Schematic diagram of equipment grounding

2.10 WIFI connection

For the configuration of Wi-Fi, please refer to the schematic wiring of Wi-Fi socket, and refer to the user manual of WIFI socket for details.

2.11 Stand-alone operation system diagram




Figure 2.17 schematic diagram of stand-alone wiring

3 Display and setup

3.1 Run data display instructions

Note: All LCD passwords are 8888

The LCD screen topology is shown in Figure 3.1, and the main interface is shown in Figure 3.2.




Figure3.2 LCD Main interface

1. The main screen displays information including solar power, grid, inverter, load, and battery, as well as the power and energy transmission routes, allowing for an intuitive view of the energy flow between various systems.
2. Negative grid power indicates selling electricity to the grid, while positive values indicate drawing electricity from the grid.
3. Negative battery power indicates charging the battery, while positive values indicate discharging the battery.
4. The photovoltaic power and load power are always positive.
5. The icon in the upper right corner is "Settings", which includes "Battery Settings", "Grid Settings", "Professional Settings", "System Settings", "Event Records", and "Device Info".




Figure3.1 LCD Topology structure diagram

3.1.1 Photovoltaic data



Click the photovoltaic panel icon on the panel of the main interface to view the PV voltage, current, stage, and energy generation. The PV stages are shown in the figure below, and the meaning of each "Stage" is described in Table 3.1.





Table3.1 PV stage illustrate

Stage	Number	Illustrate
PV Stage	101~201	Shutdown
	98	Standby
	30	Normal working

3.1.2 Battery data



Click the battery icon on the main interface to view the battery-side data, including BMS information and battery status, as shown above.

The meaning of Stage on the left side of the interface is shown in Table 3.2.

Table 3.2 DC stage description

Stage	Number	Illustrate
DC Stage	102~129	Protect shutdown
	101	Shutdown
	201	
	231	Standby
	89	
	10	Normal off-grid operation

3.1.3 Inverter data




Click on the central inverter icon on the main interface to view the voltage, current, frequency, and power on the inverter, grid, and CT sides, respectively. The right side of the interface displays the inverter stage and mode. Typically, the normal operating mode is 8, while standby is 0.

The meaning of Stage on the right side of the interface is shown in Table 3.3

Table 3.3 INV-Stage illustrate

Stage	Number	Illustrate
INV Stage	102~129	Protect shutdown
	101	
	201	Shutdown
	231	
	90	Wait for DC to power on
	89	Standby
	30	Normal grid-connected operation
	10	Normal off-grid operation

3.1.4 Grid data



Click the "Grid" icon on the main interface to view data such as grid voltage, current, frequency, and power.


3.1.5 Load data



Click the "Load" icon on the main interface to view the load grid voltage, current, and power consumption.

3.2 Run parameter setting



Note again: the password is 8888 when setting the LCD of this device.



Click the "Settings" icon on the main interface to access the system settings. Its submenus include "Battery Setting", "Grid Setting", "Professional Setting", and "System Setting", "Event" and "Device Info".

3.2.1 Battery parameter setting

Click "Battery Settings" to set battery-related parameters, "Battery Settings" is divided into three sections: "Battery Setting 1-3".



"Battery Setting1" is the interface for basic battery configuration.

① Battery and PV Settings

Bat V Max: Maximum operating voltage of battery
Bat V Min: Minimum operating voltage of battery
Max A Charge: Maximum current for working charging of battery
Max A Dischg : Maximum current for working discharging of battery
Bat Cap AH: Battery capacity size
PV1 V Max: PV1 Open Circuit Maximum Voltage
PV1 A Max: PV1 Maximum Current
PV2 V Max: PV2 Open Circuit Maximum Voltage
PV2 A Max: PV2 Maximum Current

② Battery mode selection

Bat Mode: Select either "Lithium" or "Use Bat V". This selection determines which settings in section ④ and in the "Battery Setting2" interface will be activated. The inverter's battery management logic will operate based on your choice.

③ Battery maintenance settings

Float V : Floating charging voltage, maximum charging voltage of the battery in battery voltage mode
Equ V: Equalization charging voltage, in battery voltage mode, the maximum charging voltage for regular maintenance of the battery
Equ Days: Equalization charging Interval time, regular maintenance interval for batteries

④ Maintenance settings for battery voltage/SOC control

BatActEn : Battery automatic activation enable .After selecting the second option, when the battery is protected, the device will automatically activate the battery for use
CANEn : Battery CAN communication enabled. When selecting CAN as the battery communication method on the system settings interface, please check this setting
Shutdown%/V: The device will turn off the output when the battery SOC/voltage drops below the set value(Off grid effective)
Low Bat% /V: The device will trigger an alarm when the battery SOC/voltage reaches the set value
Restart%/V : The device will resume operation when the battery SOC/voltage reaches the set value, and the AC output will be restored(Off grid effective)



The Battery Setting 2 interface allows for battery settings under conditions of power grid.


On-grid:

Dischg Pmax-W: The maximum power allowed for photovoltaic and battery discharge to the grid in grid connected state

Stop Dischg SOC-%/V: The SOC/voltage value at which the battery stops discharging when connected to the grid. If the SOC/voltage of the battery is lower than this value, it will no longer discharge

Grid Chg SOCmax-%/V: In grid-connected mode, this is the maximum SOC/voltage that can be achieved by grid charging. If the battery SOC exceeds this value, it will no longer be charged by the grid.

Chg Imax-A: Maximum battery current allowed when the battery is charging from the grid while connected.



The battery setting 3 interface is used to set the running mode of the time curve. Checking Time of Use can be used to set the values of Power-W, SOC%, and Bat-v. The settings of Power-W can limit the battery's selling and carrying power, while the SOC% and Bat-v settings are the cut-off values for battery charging or discharging. If charging the battery within the specified time range, you can checkbox Grid/GenChg.

In the grid peak shaving mode, check the Time of Use option and set the value of Power-W. The hybrid inverter operates according to the set time period and corresponding allowable conditions. If the load power exceeds the set allowable value, photovoltaic power will be used as a supplement; if the load demand is still not met, the grid power supply will be increased to meet the demand.

3.2.2 Grid parameter setting



Click "Grid Settings" in AC Setting to configure the electricity meter/CT, as well as grid and diesel generator parameters.

CT&MeterSel: Select this option in Zero EX to CT mode, and you can choose CT or meter according to your actual equipment.

Meter Type: Select the model of electric meter, and CT&Metersel can select the corresponding model after selecting meter

Meter addr: Meter address, default address is 5

CT Ratio: CT ratio, the maximum current sampled inside the device is 50mA. If the CT ratio is 100A:50mA, then set it to 100

INV Up Rated: Rated inverter output voltage (control the inverter output voltage under off-grid conditions, and follow the grid under grid-connected conditions)

Grid Hz Max: Maximum grid-connected frequency of the power grid

Grid Hz Min: Minimum grid-connected frequency of the power grid

Grid Vol Max: Maximum grid-connected voltage of the power grid

Grid Vol Min: Minimum grid-connected voltage of the power grid

INV HZ Rated : The voltage frequency of the inverter output (control the voltage frequency of the inverter output under off-grid conditions, and follow the grid under grid-connected conditions)

OnGrid A Max: Maximum grid-connected current

Gen Hz Max: Maximum grid-connected frequency of diesel generator

Gen Hz Min: Minimum grid-connected frequency of diesel generator

Gen Vol Max: Maximum grid-connected voltage of diesel generator

Gen Vol Min: Minimum grid-connected voltage of diesel generator

Grid Pmax kW: Max grid power limitation.


Reconnection Times: Power grid automatic reconnection time

GridLitEn: Enable 'Grid Pmax Kw' - - Activates the Maximum Grid Power Limit

PeNRlyEn: N-wire grounding enable, control relay connects PE and N(Off grid effective)

AcPeakShavingEn: Cooperates with the to Grid Pmax Kw activate the grid peak shaving function.

3.2.3 GEN port function settings




In AC setting2, the device to which the gen port is actually connected can be selected

Generator mode setting description:
Gen Pmax kW: This value represents the maximum power limit for the external Generator, and the system will regulate itself based on this value
Gen Mode: Default selection PQ
Gen Signal En: Output Generator signal control enable, including on-off control

Smart loads mode setting description:
StartPower W: smart load activates power setting. When the photovoltaic power exceeds this set value, the inverter will supply power to the smart load
Off Soc/ Vol V %/: When the battery SOC%/V falls below the set value, the inverter will cease power supply to the Smart load
On Soc/ Vol V %: When the battery SOC%/V is higher than the set value, the inverter will start supplying power to the Smart load
Only Bat En: When the battery SOC/voltage is higher than "On SOC%"/"On Vol V", the system will continuously supply power to the Smart Load until the battery SOC/voltage drops below "Off SOC%"/"Off Vol V", at which point the system will cut off the Smart Load
OnGrid Always on: When the inverter is connected to the grid, the system will always supply power to the smart load


AC Couple mode setting description:
CoupleFre Hz: AC coupling frequency
Off Soc/ Vol V %: When the battery SOC%/V is higher than the set value, AC couple does not participate in the system power supply
On Soc/Vol V %: When the battery soc%/v is lower than the set value, AC couple and inverter are connected to the grid to supply power to the system
AC Couple Sell Ban : AC coupling power selling prohibition

3.2.4 CT transformation ratio setting



The CT ratio data frame in the grid setting interface can set the CT ratio. When the transformer is 100A:50mA, the interface value should be filled in 100; If the transformer is 150A:50mA, the value should be filled in 150. (This value is very important. The wrong setting will affect the normal operation of the device. If you are not sure, please keep the default or contact us)

3.2.5 Operating Mode Settings



Click "professional setting" to select the equipment working mode, number of parallel operation and address during parallel operation. See operation and maintenance for detailed operation logic.

Sell First
 This mode allows the hybrid inverter to sell excess PV/battery power back to the grid. PV power is used to supply the loads and charge the battery; any surplus energy is then fed into the grid.

Zero EX to GridPort
 The hybrid inverter only powers the connected local "loads" and does not supply power to home loads or sell power to the grid. The built-in Current Transformer (CT) ensures the detected power flow to the grid side remains zero, while PV generation powers only the local loads and charges the battery.

Zero EX To CT
 The hybrid inverter powers not only the local loads connected to its load terminals but also the home loads. An external Current Transformer (CT) ensures the detected power flow to the grid side remains zero. PV generation can supply both the local and home loads, as well as charge the battery.

Solar Sell
 Solar Sell can be enabled in either Zero Export to Load or Zero Export CT mode. When activated, excess energy generated by the PV can be sold to the grid. While the inverter is operating, PV-generated power primarily supplies the loads or charges the battery before any surplus is exported to the grid.

3.2.6 System Setup

Click "system settings" to configure system parameters

SerNo.: Device serial number

BMS Addr: battery address

BMS Com: Battery communication protocol. CAN and RS485 protocol can be selected for communication. When multiple batteries are connected through RS485 protocol, the BMS address of each battery needs to be well mapped





Pack: Number of batteries

BMS Port: Battery brand

BatShareFn: Check this option when multiple units are connected to the same battery in parallel

Update En: Update enable, check to remotely upgrade equipment

Firmwave State: Firmware software version



3.3 Events Display And Device Info

Envents Records

Order	Time	Record
1	2023-11-03 12:30:40	W03:LVRT_Fault_Warning
2	2023-11-03 12:30:40	W08:Grid No_Voltage Warning
3	2023-11-03 12:30:40	W02:Comm_LCD_Lose_Warning
4	2023-11-03 12:30:40	W06:PV2 low voltage warning
5	2023-11-03 12:30:40	W05:PV1 low voltage warning
6	2023-11-03 12:30:40	W07:Battaey low voltage warning
7	2023-11-03 12:30:40	W17:Grid_Phase_Seque_Fault
8	2023-11-03 12:30:40	F06:DC_OverCurr_Failure
9	2023-11-03 12:30:40	F13:Tz_Ac_OverCurr_Fault

Click "event " on the main interface to view all operation status and historical information of the equipment. If the equipment is abnormal, please record accordingly and refer to table 4.2 in Chapter 4 for handling

Device Information

Order	Term	Version
1	Serial Number	Z1106CSM7251007
2	BMS Portocol	PylonTech
3	BMS Addr	1
4	BMS Com	CAN
5	INV Software	V0.3.0.0.1.a
6	MCU Software	V0.0.0.1.0.6
7	Dis Software	V.0.2.1.0.0.8
8	Device Model	PVESS-M06K-SA220-DD48

Click the "Device Info" icon on the main interface to view the summary of equipment information

4 Operation and maintenance

4.1 Trial run

When the device and other device cables such as batteries are properly installed and connected, start the device by following the following steps: The LED flashing signal definition and LCD key definition are described in Table 4.1: Hold down UP and ENTER at the same time to restart the LCD.

- Turn on the power supply of grid, battery, photovoltaic switch, the LCD will light up.
- Select a meter or CT and set its address based on the actual used. If neither is used, select None .The setting position is on AC Setting1 on the LCD screen.
- Select a Grid standard based on the actual power grid usage. If no corresponding standard is available, select the general standard. The setting position is on AC Setting3 on the LCD screen.
- Select the battery control mode based on the actual use of the battery.This setting is located in the LCD battery device screen Battery Setting1.When the system is not connected to the battery, but is connected to the PV or power grid, in this case, the system can still work without selecting Bat Mode.
- Press the ON/OFF button to turn on the device.The round button located on the bottom side of the housing.
- For details about the operating mode, see descriptions of the single machine Operating Mode.

Table 4.1 Definition of LCD keys

	LED definition	Instructions
DC	The green light continues to shine.	PV connection normal
AC	The green light continues to shine.	Power grid connection normal
Normal	The green light continues to shine.	Normal inverter operation
Alarm	Red light flashing	Fault or warning
ESC	Exit setting	
UP	Go to the previous option	
DOWN	Go to the next option	
ENTER	ENTER certainty	

4.2 Stand-alone operation and logic description

When the stand-alone operation, The K6 dialing code on the internal and external interface board of the device needs to be opened, set ON, as shown in Figure 4.1.




Figure 4.1 Schematic diagram of DIP terminal ON

4.3 Parallel operation and logical explanation

When running in parallel, the internal and external interface board of the first device and the last device is placed as shown in Figure 4.1, K6 dialing code needs to be opened(ON). This is shown in Figure 4.2 for example, the grid-connected parallel wiring diagram, the three devices need to be placed, and the K6 dialing code of 1# and 3# needs to be opened, and the dialing code of 2# does not need to be opened.

4.3.1 Set entry path description

Click “Setting” ,display at screen on the home page, and click "Professional Setting" in the setting interface to enter the working mode setting interface and select the address setting of the device, Select the device parallel address setting.

4.3.2 Parallel operation logic

When multiple parallel machines are connected, first connect the communication network lines ports Parallel_A and Parallel_B and CAN communication lines port J21 CAN2H and CAN2L of the parallel equipment to form a ring connection system, then set the address parameters of each module respectively after power-on, the address setting of three parallel units is set. Set the number of parallel units "Parallel Units Total Num" and the inverter address "Inv Addr" (can only be an odd number, starting from 1 and cannot be repeated). The hybrid inverter module with Inv Addr = 1 will be defined as the master by the system, and the hybrid inverter module with Inv Addr as other odd numbers will be defined as the slave by the system.

In this mode, all hybrid inverters will run synchronously according to the scheduling of the master, so when powering up, the power button of all slaves should be pressed first, and finally the power button of the master should be pressed, so that the master can automatically identify the slave state in the merging system, which is conducive to logic and power regulation when power is turned on and

connected to the grid. If there is an individual slave failure or communication interruption in the normal operation, the master will automatically identify and withdraw the slave from the whole parallel system and re-regulate the power. When the fault slave returns to normal, the host will automatically identify and merge the slave into the system and re-regulate the power. All the working modes of the parallel system are the same as those of the stand-alone machine. It should be noted that the parallel machine only needs a set of external CT, which is connected to the grid power trunk line, and the sampling signal is connected to the CT input port of the master inverter.

4.3.3 Parallel system wiring diagram

See Figure 4.2 for grid-connected parallel wiring and Figure 4.3 for off-grid parallel wiring. When connected to Grid, Gen or AC Couple, grid-connected operation requires wiring according to Figure 4.2; when neither the grid nor the generator is connected, off-grid parallel operation requires wiring according to Figure 4.3 (in the actual wiring process, the BMS communication line, parallel communication line, and BAT line need to be routed from the corresponding ports, and schematic diagrams 4.2 and 4.3 are only used to illustrate the specific location of the wiring position).




Figure 4.2 On-grid parallel wiring diagram




Figure 4.3 Off-grid parallel wiring diagram

4.4 Example of five parallel inverter on grid

4.4.1 Grid and load connection

Figure 4.4 below shows the connection diagram of five inverters (No. 1, 3, 5, 7, 9). K0 is the main circuit breaker of the power grid. K11, K13, K15, K17, K19 are load circuit breakers, K1 is the load circuit breaker. K02 is a home load circuit breaker. Each inverter has its own power grid circuit breaker respectively K01, K03, K05, K07, K09.




Figure 4.4 The connection diagram of five inverters

4.4.2 Parallel cable connection and check




Figure 4.5 Parallel cable connection

Step 1:

- a) Check whether the cable connection is correct as shown in Figure 4.4 (for BMS connection, CT or meter connection, battery connection, and ground cable connection, refer to the previous chapter.) Check whether the positive and negative batteries are consistent.

- b) Please check whether the parallel cable connection is correct as shown in Figure 4.5.
- c) Set the K6 DIP switch in the middle of the first and last inverters to ON, and turn off the others.

Step 2:

- a) Only turn on the Grid circuit breaker K0.
- b) Check the phase voltage of each inverter grid breaker (inside)input port, and check the same phase voltage difference between grid main break and inverter grid breaker is near zero.checking K01,K03,K05,K07,K09,if the voltage is not normal please check the wire connection between grid and inverter grid breaker. if the connection all normal, go to step 3.

Step 3:

- a) Turn on K01,K03,K05,K07,K09. Keep battery not add to inverter and those load breakers off(K11,K13,K15,K17,K19).
- b) Check the display lcd screen is on, and the grid data page shown the grid voltage and frequency are normal.
- c)For details about how to set the device address, Set the master address to 1, and set the slave address to 3, 5, 7, and 9.
- d) Battery sharing Settings, if the same battery group is used, please check BatShareEn in system Settings, and set the BMS communication mode and communication address.
- e) For CT or smart meter Settings, please select the metering mode used by the system in AC Settings1, if both are no-used, please select None.
- f) To select the battery control mode, please select voltage control or lithium battery control mode in Battery Setting1 according to the actual battery type. If the battery is not connected, you can run without selecting.
- g) Turn on round button located on the bottom side of the housing. The sequence is to close the slave 3/5/7/9 first, and finally close the master 1.
- h) After the grid relay is closed, check whether the voltage on the load page of the main screen is normal.
- i) Check the voltage difference of same phase between inverter grid input port and inverter's load output port ,make sure all voltage difference of each inverter are near zero.
- j) Check the voltage difference of same phase between inverter's load output port and load breaker(K11,K13,K15,K17,K19) ,make sure all voltage difference of each inverter are near zero. if the voltage difference is not near zero, check the wire connection between inverter load port and load breaker.

k) If all are normal, go to step 4.

Step 4:

- a) Turn on one of the load circuit breakers such as K11.
- b) Check the voltage difference of same phase between breaker K13(K15,K17,K19)'s input port and output port, make sure all voltage difference of each inverter are near zero.
- c) If the voltage difference is not near zero, check the connection between the load circuit breaker output port and the main load circuit breaker K1.
- d) If all in-phase voltage differences are close to zero, open the load circuit breaker K13 (K15, K17, K19).
- e) If all load circuit breakers are turned on, the connection check is completed. Turn off the load circuit breaker, release the round button, turn off all network circuit breakers

4.4.3 ON-Grid startup parallel

- a) Before the parallel operation, please ensure that all lines have been checked and correct.
- b) Close the main grid circuit breaker K0, close the inverter internal grid circuit breaker (K01, K03, K05, K07, K09).
- c) Check whether the grid interface voltage and frequency of each inverter are normal.
- d) Close all battery circuit breakers and check whether the battery interface voltage of each inverter is normal. If it is lithium battery or SOC control mode, check whether the SOC value is displayed correctly next to the battery icon on the main interface.
- e) Close all load circuit breakers (K11, K13, K15, K17, K19).
- f) Press the round buttons on the bottom side of all **slaves**.
- g) Press the round button on the bottom side of the **master**.
- h) After the power grid relay is closed, check whether the voltage on the load page of the main screen is normal. Click the middle inverter icon on the main screen of each device to check whether the INV Stage is 30-Working.
- i) Close the total load circuit breaker for power supply, and the operation is complete.

4.4.4 Off-grid startup parallel

- a) Before the parallel operation, please ensure that all lines have been checked and correct.
- b) Close all battery circuit breakers and check whether the battery interface voltage of each inverter is normal. If it is lithium battery or SOC control mode, check whether the SOC value is displayed correctly next to the battery icon on the main interface.
- c) Close all load circuit breakers (K11, K13, K15, K17, K19).

- d) Press the round buttons on the bottom side of all **slaves**.
- e) Press the round button on the bottom side of the **master**.
- f) Check whether the voltage on the load page of the main screen is normal. Click the middle inverter icon on the main screen of each device to check whether the INV Stage is 10-Working.
- h) Close the total load circuit breaker for power supply, and the operation is complete.

4.4.5 Shut down the Inverter

- a) Turn off total load circuit breaker K1
- b) Turn off all load circuit breakers (K11, K13, K15, K17, K19).
- c) Release the round button on the bottom side of the master
- d) Release all round buttons on the bottom side of the slaves
- e) The system exits from operation.

4.5 Fault alarm and handling

If the device fails to start, click the Events icon on the home screen to view historical alarms and rectify faults one by one. Through the analysis of the above methods, determine the cause of the fault, and then determine the appropriate solution according to the field conditions. Table 4.2 lists the device alarm information and handling methods.

- Periodically check whether the wiring of each part of the inverter is firm and loose, especially carefully check the fan, power module, input terminal, output terminal, and grounding.
- Once the alarm stops, do not start immediately, should find out the cause and repair the restart, check should be strictly in accordance with the inverter maintenance manual prescribed steps.
- Operators must be specially trained to identify the causes of general failures and be able to troubleshoot them, such as skilfully replacing fuses, components and damaged circuit boards. Personnel without training are not allowed to operate the equipment.
- If there is an accident that is not easy to exclude or the cause of the accident is unclear, a detailed record of the accident should be made and the inverter manufacturer should be notified in time for solution.

Table 4.2 Device alarm information and handling methods

NO.	Warning	Handling Suggestions
W01	Insulation_Warning	<ol style="list-style-type: none"> 1.Please check that the ground wire is connected correctly. 2.Seek help from us, if you cannot return to normal.
W02	Comm_LCD_Lose_Warning	<ol style="list-style-type: none"> 1.Please Check the communication line between the LCD and the control board. 2.Seek help from us, if you cannot return to normal.
W03	LVRT_Fault_Warning	Grid voltage fluctuation,the equipment records this event.
W04	Fan_Fault_Warning	<ol style="list-style-type: none"> 1.Please check the fan outside the enclosure for foreign objects. 2.Restart the equipment, please contact us if you still fail.
W05	PV1 low voltage warning	<ol style="list-style-type: none"> 1.Please check the PV1 voltage range in the equipment system settings. The PV voltage setting value is between (150 ~ 500) V; 2.At present, the light is weak, and the actual photovoltaic power is low; 3.Please contact us or PV supplier again.
W06	PV2 low voltage warning	<ol style="list-style-type: none"> 1.Please check the PV2 voltage range in the equipment system settings. The PV voltage setting value is between (150 ~ 500) V; 2.Please contact us or PV supplier again.
W07	Battery low voltage warning	<ol style="list-style-type: none"> 1.Please check whether the battery voltage is too low; 2. Check whether the battery voltage lower limit on the battery setting page is higher than the actual battery. The minimum battery voltage setting value is between (10 ~ 55) V; 3.Check whether the maximum discharge current on the battery page exceeds the maximum battery operating current; 4.Please contact us or battery suppliers if you are alert again.
W08	ACgrid low voltage warning	<ol style="list-style-type: none"> 1.Please check whether the grid voltage is too low; 2.Check whether the lower limit of AC voltage is too high on the AC setting page. The minimum grid voltage setting value is between (198 ~ 220) V. 3.Please contact us if you are alert again.
W09	ACgen low voltage warning	<ol style="list-style-type: none"> 1.Please check whether the gen voltage is too low; 2.Check whether the lower limit of Gen voltage is too high on the AC setting page. The minimum gen voltage setting value is between (198 ~ 220) V. 3.Please contact us if you are alert again.
W10	AC_Volt_Unbalance_Warning	<p>The AC voltage amplitude is unbalanced</p> <ol style="list-style-type: none"> 1.Please check the AC wiring of the equipment and restart after errors; 2.If the restart failed and reported the error again, please contact us.

W11	AC_PLL_Warning	<p>Failed to detect the output phase lock after power-on</p> <ol style="list-style-type: none"> 1.Please check the AC wiring of the equipment and restart after errors; 2.If the restart failed and reported the error again, please contact us.
W12	Power_Derate_Warning	The equipment is output derated due to environmental influence, records this event.
W14	Heatsink_LoTemp_Warning	Low temperature warning due to environmental influences
W15	BMS Communication Warning	<ol style="list-style-type: none"> 1.Please check whether the BMS communication cable is well connected. 2.If you still alert, please contact us.
W16	Grid voltage_Fault	<ol style="list-style-type: none"> 1.The output voltage is not within the equipment setting range, and it may be caused by the device stop. 2.If you still alert, please contact us.
W17	grid_GridPhhaseSeque_Fault	<ol style="list-style-type: none"> 1.Check the device wiring and the equipment of each power supply normally. restart the device. 2.If you still alert, please contact us.
W18	AC_Freq_Fault	<ol style="list-style-type: none"> 1.Please check the grid frequency range value in the equipment system. 2.Please check whether the grid wiring is correct. 3.If you still alert, please contact us.
W19	gen_voltage_Fault	<ol style="list-style-type: none"> 1.The output voltage is not within the equipment setting range, and it may be caused by the device stop. 2.If you still alert, please contact us.
W20	Gen_GridPhhaseSeque_Fault	<ol style="list-style-type: none"> 1.Please check whether the gen wiring is correct. 2.Restart the equipment, please contact us if you still fail.
W21	GEN_Freq_Fault	<ol style="list-style-type: none"> 1.Please check the gen frequency range value in the equipment system. 2.Please check whether the gen wiring is correct. 3.If you still alert, please contact us.
W23	Load low voltage warning	<ol style="list-style-type: none"> 1.Please check whether the load line wiring is correct. 2.Please check the range of AC voltage. 3.Restart the equipment, please contact us if you still fail.
W24	PV2_VoltHigh_warning	<ol style="list-style-type: none"> 1.Please check the PV2 voltage range in the equipment system settings. The PV voltage setting value is between (150 ~ 500) V. 2.Please contact us or PV supplier again.
W25	PV1_VoltHigh_warning	<ol style="list-style-type: none"> 1.Please check the PV1 voltage range in the equipment system settings. The PV voltage setting value is between (150 ~500) V. 2.Please contact us or PV supplier again.

W26	Bat_VoltHigh_warning	<ol style="list-style-type: none"> 1.Please check whether the battery voltage is too high. 2.Please check whether the upper limit of the battery voltage range in the equipment system is too low. The highest battery voltage setting value is between (15 ~ 60) V. 3. Please contact us or battery suppliers if you are alert again.
F01	DC Inversed Failure	<ol style="list-style-type: none"> 1.Please check whether the positive and negative batteries are reversed. 2.If you still alert, please contact us.
F02	Insulation_Failure	<ol style="list-style-type: none"> 1.Please check that the ground wire is connected correctly 2.Seek help from us, if you cannot return to normal.
F03	EEPROM_Read_Failure	Restart the equipment, please contact us if you still fail.
F04	EEPROM_Write_Failure	Restart the equipment, please contact us if you still fail.
F05	DC soft start Failure	<ol style="list-style-type: none"> 1.Please check whether the battery voltage is normal. 2.Please check whether the battery voltage setting value of the device is normal, The battery voltage setting value is between (15 ~ 60) V. 3. Please contact us or battery suppliers if you are alert again.
F06	Tz_Dc_OverCurr_Fault	<ol style="list-style-type: none"> 1.Please check the battery current limit value in the equipment system. 2.Please check whether the PV and battery wiring of the equipment are normal. 3.Cut off all power source and wait for 2 minutes to discharge the inverter.Open all power circuit breakers and restart the device. 4.If the restart failed and alarmed again, please contact us.
F07	DC_OverCurr_Failure	<ol style="list-style-type: none"> 1.Please check the battery current limit value in the equipment system. 2.Please check whether the PV and battery wiring of the equipment are normal. 3. Cut off all power source and wait for 2 minutes to discharge the inverter.Open all power circuit breakers and restart the device. 4. If the restart failed and alarmed again, please contact us.
F08	AuxPowerBoard_Failure	Restart the equipment, please contact us if you still fail.
F09	IGBT_Failure	Restart the equipment, please contact us if you still fail.
F11	AC_Main Contactor_Failure	Restart the equipment, please contact us if you still fail.
F12	AC_Slave Contactor_Failure	Restart the equipment, please contact us if you still fail.
F13	Tz_Ac_OverCurr_Fault	<ol style="list-style-type: none"> 1.Please check whether the backup load power is within the range. 2.Restart and check whether it is normal. 3.Seek help from us, if you cannot return to normal.

F14	AC_OverCurr_Failure	1.Please check whether the backup load power is within the range. 2.Restart and check whether it is normal. 3.Seek help from us, if you cannot return to normal.
F15	GFCI_Failure	1.Please check the wiring of the equipment and restart after errors. 2.If the restart failed and reported the error again, please contact us.
F16	Tz_COM_OC_Fault	1.Please check whether the backup load power is within the range. 2. Restart and check whether it is normal. 3.Seek help from us, if you cannot return to normal.
F17	BusUnbalance_Fault	Restart the equipment, please contact us if you still fail.
F18	Load_voltage_Fault	1.Please check whether the load line wiring is correct. 2.Please check the range of AC voltage. 3.Restart the equipment, please contact us if you still fail.
F24	Grid_Overload_Fault	1.Please check whether the backup load power is within the range. 2.Restart and check whether it is normal. 3.Seek help from us, if you cannot return to normal.
F25	Gen_Overload_Fault	1.Please check whether the backup load power is within the range. 2.Restart and check whether it is normal. 3.Seek help from us, if you cannot return to normal.
F26	DC_VoltHigh_Fault	Restart the equipment, please contact us if you still fail.
F27	DC_VoltLow_Fault	Restart the equipment, please contact us if you still fail.
F28	AC_BackFeed_Fault	Restart the equipment, please contact us if you still fail.
F29	Heatsink_HiTemp_Fault	Overhigh temperature alarm
F30	PV1 arc Failure	1.Please check the wiring of the equipment and restart after errors. 2.If the restart failed and reported the error again, please contact us.
F31	PV1 Inversed Failure	1.Please check PV1 terminal is correct. 2.If you still alert, please contact us.
F32	PV2 Inversed Failure	1.Please check PV2 terminal is correct. 2.If you still alert, please contact us.

4.6 Product routine maintenance suggestions



- Ensure that all the switches on the DC side and AC side of the energy storage controller, battery components, and AC power distribution cabinet are turned off.
- After the AC/DC switch of the energy storage converter is turned off, some components of the hybrid inverter still have residual voltage. Please wait at least 5 minutes before maintaining the hybrid inverter to prevent electric shock!

4.6.1 Routine inspection

- Check whether the temperature of each circuit breaker of the inverter is too high during the daily peak load generally not more than 90°C .
- Check whether the ambient temperature of the inverter is too high for example, ventilate and dissipate the inverter when the temperature is too high .
- The values of inverter, box transformer voltage, current and power are compared during daily peak load.
- Daily check whether the inverter sound is normal.
- Check fault records daily to see if new faults occur.

4.6.2 Monthly inspection

- Check the wiring of each part of the inverter regularly every month, whether it is firm, whether it is loose, and check whether the fan, power module, and terminal block are burned or heated.
- When the inverter needs to be started and stopped, strictly follow the instructions provided by the manufacturer.
- Operators through professional training, no violations of rules and regulations.

4.6.3 Quarterly inspection

- Tighten the screws on the AC and DC sides of the inverter every six months.
- Dust the inverter once every three months.
- In hot weather, open the inverter room vent for ventilation and heat dissipation.

5 Transportation and storage

5.1 Product Shipping Requirements

5.1.1 Logistics

- The company's inverter is delivered by a professional logistics company, and the logistics company will communicate with the dealer before delivery. Pay attention to accurately grasp the location and contact person of the delivery point, plan the delivery route, and preferably have an alternate route.
- The logistics drivers are very professional. No alcohol, drugs, or phone calls are allowed during driving. The drivers will stop to contact the distributor and consignee before arriving at the destination. Pay attention to communicating in advance, it is best not to disturb the driver halfway and distract the driving attention.
- The type of transport vehicle must be selected according to the actual road conditions. If it is too large, it may exceed the limit and cannot pass, or an unexpected situation may occur.

5.1.2 Unloading and handling

- You must have a special equipment operation certificate to drive a forklift, and you must pay attention to the inspection, and remember to prohibit unlicensed operation.
- Handlers must be equipped with relevant PPE.
- If there is no delivery point for forklift unloading, the pallet can only be removed on the logistics vehicle, and 4 people cooperate to unload one set each time.

5.2 Product storage environment requirements

If the inverter is not put into use immediately, it must be stored as required.

- Pack the inverter in its original packaging, retain the desiccant, and seal it with tape.
- The storage temperature should be kept at $-40^{\circ}\text{C}\sim+70^{\circ}\text{C}$. the relative humidity should be kept at $5\%\text{RH}\sim95\%\text{RH}$.
- Store in a clean and dry place, and prevent the erosion of dust and water vapor.
- Inverters with an outer packaging size of $600*420*280$ width×height×depth can be stacked up to 4 layers. When stacking, please place the inverter carefully to avoid personal injury or equipment damage caused by the equipment falling over. Please place it upward first, and it is forbidden to invert it.
- Periodic inspection is required during storage. If insects and rats are found to bite, the packaging materials need to be replaced in time.
- After long-term storage, the inverter needs to be inspected and tested by professionals before it can be put into use.



6 Legal Notices

In addition to the product warranty described above, the state and local laws and regulations provide financial compensation for the product's power connection (including violation of implied terms and warranties). The company hereby declares that the terms and conditions of the product and the policy cannot and can only legally exclude all liability within a limited scope.

7 Attachments


Attachments 1 Network port definition description

MARK	J19-1	J19-2	J19-3	J19-4	J19-5	J19-6	J19-7	J19-8
Definition	NO2	COM2	NO1	COM1	CT1+	CT1-	BAT-TEMP	BAT-TEMP-
Function	Reserved		Gen start control		External A-phase CT1 sampling input		Battery temperature sampling input	
MARK	J20-1	J20-2	J20-3	J20-4	J20-5	J20-6	J20-7	J20-8
Definition	IN1+	IN1-	IN2+	IN2-	IN3+	IN3-	RSD+	RSD-
Function	Reserve for spare						+12Voutput	12VGND
MARK	J21-1	J21-2	J21-3	J21-4	J21-5	J21-6	J21-7	J21-8
Definition	CANL2	CANH2	CANL2	CANH2	RS485A1	RS485B1	SW 1	SW 2
Function	Parallel CAN communication				Meter communication		PV control	
RJ45-	1	2	3	4	5	6	7	8
BMS	RS485B3	RS485A3	NC	CANH	CANL	NC	RS485A3	RS485B3
Function	BMS-485 communication			BMS-CAN communication			BMS-485 communication	
Parallel_A	CANH1	CANL1	SNY-01	SNY-02	ISOGND1	ISOGND1	CAN-SMH	CAN-SML
Function	Parallel synchronous communication							
Parallel_B	CANH1	CANL1	SNY-01	SNY-02	ISOGND1	ISOGND1	CAN-SMH	CAN-SML
Function	Parallel synchronous communication							
Meter_485	RS485B1	RS485A1	NC	NC	NC	NC	RS485A1	RS485B1
Function	Meter communication						Meter communication	
MODBUS	RS485B4	RS485A4	NC	RS485B2	RS485A2	NC	RS485A4	RS485B4
Function	EMS monitoring			Reserve background monitoring communications			EMS monitoring	



Attachments 2 CT size and model

CTSA016 100A:50mA



Attachments 3 Hybrid Inverter data

Datasheet

Model	Plu -5G1-LE	Plu -6G1-LE	Plu -6.6G1-LE
Product Type	Hybrid Inverter		
Battery Input Data			
Battery Type	Lead acid or Lithium-ion		
Battery Voltage(V)	48(40V-60V)		
Battery Charge/Discharge Current(A)	110	135	150
Charging Strategy for Li-Ion	Self-Adaption to BMS		
PV Input Data			
Max.PV Input Power(W)	7500	9000	9900
Max.PV Input Voltage(V)	500		
Start-up Voltage(V)	125		
PV Input Voltage Range (V)	125-500		
Rated PV Input Voltage(V)	370		
MPPT Input Range(V)	150-425		
Full Load MPPT Voltage Range(V)	300-425		
Max Operating PV Input Current(A)	18+18	18+18	18+18
Max.PV Input Short-Circuit Current(A)	27+27	27+27	27+27
No.of MPPT Trackers/No.of Strings per MPPT Tracker	2/1+1		
AC Input/Output Data			
Rated AC Input/Output Active Power(W)	5000	6000	6600
Max. AC Input/Output Apparent Power(W)	5500	6600	7150
Peak Power (off-grid)(W)	2 times of rated power, >10S		
Rated AC Input/Output Current(A)	21.7	26.1	28.7
Max. AC Input/Output Current(A)	23.9	28.7	31.6

Max.Continuous AC Passthrough(grid to load) (A)	40
Short Circuit Protection Current(A)	73
Grid Connection Form	L+N+PE
Rate Input/Output Grid Frequency/Range	50Hz/60Hz
Power Factor Adjustment Range	0.8 leading-0.8 lagging
Total Current Harmonic Distortion THDI	THD<3%(Linear load <1.5%)
DC Injection Current	<0.5%In
<i>Efficiency</i>	
Max.Efficiency	97.60%
Euro Efficiency	96.50%
MPPT Efficiency	99%
<i>Equipment Protection</i>	
DC Polarity Reverse Connection Protection	YES
AC Output Overcurrent Protection	YES
AC Output Overvoltage Protection	YES
AC Output Short Protection	YES
Thermal Protection	YES
DC Terminal Insulation Impedance Monitoring	YES
Ground Fault Current Monitoring	YES
Island Protection Monitoring	YES
DC Input Switch	No
Residual Current Detection (RCD)	YES
Surge Protection Level	TYPE II(DC),TYPE II(AC)
<i>Protection</i>	
Integrated	PV Input Lightning Protection, Anti-islanding Protection, PV String Input Reverse Polarity Protection, Insulation Resistor Detection, Residual Current Monitoring Unit, Output Over Current Protection, Output Shorted Protection

Output Over Voltage Protection	DC Type II/AC Type III		
<i>Certification and Standards</i>			
EMC/Safety Regulation	IEC/EN 62109-1 IEC/EN 62109-2,IEC/EN 61000-6-1, IEC/EN 61000-6-3		
<i>General Data</i>			
Operating Temperature Range	-40-60℃ (>45℃ derating)		
Permissible Ambient Humidity	0-100%		
Permissible Altitude	2000m		
Noise	<40dB		
With/without external fan	√	√	√
Ingress Protection(IP) Rating	IP65		
Inverter Topology	Non-Isolated		
Over Voltage Category	OVC II(DC),OVC III(AC)		
Cabinet size(W*H*D)(mm)	305*450*165 (Excluding connectors and brackets)		
Weight(kg)	14.8		
Installation Style	Wall-mounted		

Version No: 2026.1.8 V2.7

Zhejiang Chisage New Energy Technology Co., Ltd.

 Tel: +86 150 5749 1826

 Email: info@chisagess.com

 Web: www.chisagess.com

 Add: No.1828, Fuqing South Road, Panhuo Street, Yinzhou District, Ningbo City,
Zhejiang Province, China 315000
